

EPC
File Edit View Tools Info Help

VIN DMS English ? ?

Vehicle Content Illustration Pick List Search Administration


Short block - Engine mounting (1986 - 1989)

Parts Picklist Notes

Pos	Article	Usage	Qty	Part No.
☐ 1	Engine pad		1	83 39 608
☐ 2	Cap		1	83 39 632
☐ 3	Screw	NLS-USE 7978224	2	79 72 342
☐ 5	Screw		1	80 98 394
☐ 6	Screw	NLS-USE 7978224	2	79 77 242
☐ 7	Bushing		2	75 44 265
☐ 8	Engine anchorage	LH	1	93 23 759
☐ 9	Engine anchorage	RH	1	93 24 930
☐ 9	Engine anchorage	B202I, RH	1	93 67 988
☐ 10	Engine pad	LH	1	93 69 307
☐ 10	Engine pad	B202I, LH	1	75 43 408
☐ 11	Engine pad	RH	1	93 69 315
☐ 11	Engine pad	B202I, RH	1	75 43 416
☐ 12	Screw		2	75 43 432
☐ 13	Screw		2	80 82 935
☐ 14	Screw		2	93 16 415
☐ 15	Engine anchorage		1	93 23 742

Start | The Sa... | Saabn... | Scann... | TSN: ... | EPC | 10:20 PM

Fuel system - Filler pipe - Hose (1990 - 1993) Also valid for CV 1994




Parts Picklist Notes

Pos	Article	Usage	Qty	Part No.
☐ 1	Filler cap	NLS-USE 4391058	1	89 82 209
☐ 2	•Gasket		1	75 11 751
☐ 3	Filler pipe	Without catalytic converter.	1	75 30 553
☐ 3	Filler pipe	With catalytic converter.	1	93 35 118
☐ 4	•Plastic plug	ELCD	1	75 36 840
☐ 5	•Stop		2	83 15 475
☐ 6	•Gasket		1	93 49 838
☐ 7	Draining pipe		1	83 23 941
☐ 8	Hose	L=52 MM	1	93 63 284
☐ 9	Bushing		1	79 61 329
☐ 10	Filler pipe	Ch. M5001204-- Ch. M7029124--	1	41 58 069
☐ 11	Hose		1	75 25 421
☐ 12	Hose	Ch. L3003532-- Ch. L5000620-- Ch. L7009221--	1	75 25 421
☐ 13	Hose	SN	1	75 28 920
☐ 13	Hose	CK	1	75 28 912
☐ 13	Cable	CV, NLS-USE 4023800	1	40 19 345
☐ 14	Hose		1	75 39 133
☐ 15	Hose clamp		4	79 70 130
☐ 16	Hose		1	40 18 354
☐ 17	Hose clamp		2	83 32 587

EPC
File Edit View Tools Info Help

Vehicle Content Illustration Pick List Search Administration

Intake and exhaust system - Throttle body (1986 - 1989), B202




Parts Picklist Notes

Pos	Article	Usage	Qty	Part No.
☐ 1	Throttle body	1986, TURBO, M	1	75 22 444
☐ 1	Throttle body	1986, TURBO, M, ME	1	75 22 931
☐ 1	Throttle body	1986-1987, (7563463) For TURBO with catalytic converter.	1	75 69 577
☐ 1	Throttle body	1986-1988 For TURBO with catalytic converter. Engine J090913-	1	74 87 705
☐ 1	Throttle body	1986-1987, (7518228) For I with catalytic converter.	1	75 69 593
☐ 4	Throttle valve, shutter		1	83 53 484
☐ 5	Throttle shaft	NLS-USE 8057259, 9107624	1	75 04 673
☐ 6	Seal		2	83 57 345
☐ 7	Screw		2	80 59 073
☐ 8	Cover		1	75 05 423
☐ 9	O-ring		1	75 06 264
☐ 10	O-ring	1986, NLS-USE 7974546	1	81 09 563
☐ 11	Screw	NLS-USE 7985187	6	75 07 080
☐ 12	Usage: 1986, NLS-USE 7974546		1	75 62 729

Start | The Saab ... | Saabnet.c... | Site Map - ... | Clutch Mas... | EPC | 8:56 PM


Cooling system - Oil cooler - Engine and automatic transmission (1986 - 1989), A



Parts Picklist Notes

Pos	Article	Usage	Qty	Part No.
☐ 1	Oil cooler Ch. H2012508-- Ch. H3015248-- Ch. H7018678--	A	1	75 46 963
☐ 2	Oil cooler Ch. G2010831-- Ch. G3007910-- Ch. G7012543--	ENGINE	1	75 46 567
☐ 3	Hydraulic hose	1988-1989, A	1	75 49 868
☐ 4	Hydraulic hose Ch. H2012508-- Ch. H3015248-- Ch. H7018678--	A, NLS	1	75 47 847
☐ 5	Hydraulic hose	A	1	75 44 372
☐ 6	Hydraulic hose	A	1	75 46 385
☐ 7	Hydraulic hose Ch. G2010831-- Ch. G3007910-- Ch. G7012543--	ENGINE	1	75 46 476
☐ 7A	• O-ring Ch. G2010831-- Ch. G3007910-- Ch. G7012543--		2	79 77 580
☐ 8	Hydraulic hose Ch. G2010831-- Ch. G3007910-- Ch. G7012543--	ENGINE	1	75 46 484
☐ 8A	• O-ring Ch. G2010831-- Ch. G3007910-- Ch. G7012543--		2	79 77 580
☐ 9	Hydraulic hose	A	1	75 47 821

Supercharging system - Turbocharger (1990 - 1993), TURBO Also valid for CV 1994




F4421 AAC90

Parts Picklist Notes

Pos	Article	Usage	Qty	Part No.
☐ 37	Tube	B202S	1	40 22 190
☐ 38	Hose	B202S	1	75 26 288
☐ 39	Hose	B202S	1	40 22 182
☐ 40	Hose clamp	B202S	3	79 70 130
☐ 41	Hose clamp	B202S	1	79 70 155
☐ 42	Sealing kit	Goto 2 - 2090	X	88 18 569
☐ 43	Tube	M	1	75 49 918
☐ 43	Tube	A	1	75 49 926
☐ 44	Hose clamp		1	79 70 049
☐ 45	Nut		4	79 67 953
☐ 46	Nut		1	81 45 542
☐ 47	Ferrule		1	81 32 227
☐ 48	Stud	M	2	75 49 991
☐ 48	Stud	A	2	75 99 509
☐ 49	Nipple		1	75 84 790
☐ 50	Gasket		1	81 24 158
☐ 51	Tube	1990	1	75 88 718
☐ 52	Hose	1990	1	74 82 953
☐ 53	Water pipe	1990	1	74 81 427
☐ 54	Hose clamp	NLS-USE 7970056	2	79 63 515
☐ 55	Screw		1	75 83 628
☐ 56	Gasket		2	81 24 158
☐ 57	Barin screw	1990	1	81 23 903


Supercharging system - APC system (1986 - 1989)



Parts Picklist Notes

Pos	Article	Usage	Qty	Part No.
☐ 2	Knock sensor	1987-1989	1	75 68 801
☐ 3	Pressure sensor		1	93 42 064
☐ 4	Solenoid valve		1	75 17 477
☐ 5	Control module		1	75 24 119
☐ 5	Control module	1987-1989, B201TURBO	1	75 67 704
With catalytic converter.				
☒ 5	Electronic unit	B202TURBO	1	75 24 127
☐ 5	Electronic unit	1987-1989, B202TURBO, LHD, US	1	75 66 599
☐ 5	Elect	Usage: 1987-1989, B202TURBO, LHD, US LHD, CA, US	1	75 24 127
☐ 6	Bracket		1	93 42 239
☐ 7	Expanding nut		2	79 73 456
☐ 8	Screw		2	80 19 721
☐ 9	Screw		2	79 22 800
☐ 10	Screw		4	80 19 713
☐ 11	Screw	1987-1989	1	81 25 197
☐ 12	Screw	NLS-USE 7922800	2	79 72 359
☐ 15	Nut		4	79 73 365
☐ 17	Bushing		1	83 25 656
☐ 18	Nipple	NLS-USE 4160263	1	93 42 270
☐ 19	Hose		1	75 25 777
☐ 20	Hose		1	93 88 752

Generator - Bosch 80A (1986 - 1989)



Parts Picklist Notes


Pos	Article	Usage	Qty	Part No.
☐ 20	Stay		1	75 06 272
☐ 21B	Rubber bushing		2	93 54 770
☐ 23	Washer		2	73 11 772
☐ 24	Screw		1	80 98 089
☐ 25	Screw		2	80 98 113
☐ 26	Washer		2	80 29 985
☐ 27	Nut	1988-1989	1	81 51 243
☐ 29	Washer	1986-1988	1	80 73 108
☒ 30	Adjustment screw	1986-1988, NLS-USE 7399769, 7549488	1	75 12 106
☐ 31	Nut	1986-1988	1	79 71 922
☐ 35	Screw	1986-1988, NLS-USE 7979255	1	80 84 253
☐ 35A	Nut	1988-1989	1	81 51 243
☐ 36	Ground cable		1	85 87 222
☐ 39	Nut	1988-1989	1	81 51 235
☐ 40	Washer		1	79 33 849

Model SAAB 900 1988

Group 3A Electrical, general

Section 0160 Filter ON

Ignition system - Ignition distributor (1986 - 1989), B202I




F0478 90086

Parts Picklist Notes


Pos	Article	Usage	Qty	Part No.
☒ 1	Ignition distributor	1986-1987, LHD, US	1	75 61 798
☐ 2	• Distributor cap		1	75 01 216
☐ 3	• Rotor		1	75 64 420
☐ 5	• Spring		2	75 19 085
☐ 9	• O-ring	NLS-USE 9176470	1	75 19 143
☐ 10	Repair kit	Goto 3A - 1480 For distributor 75 68 798.	X	75 88 304
☐ 11	Bracket		1	83 62 287
☐ 12	Screw	NLS-USE 9166323	1	80 82 950
☐ 27	Contact housing	1986-1987 Goto 3B - 370		85 74 097

Ignition system - Ignition distributor (1986 - 1989), B202TURBO



Pos	Article	Usage	Qty	Part No.
☐ 1	Ignition distributor Engine ~J088764	NLS-USE 7481393, 8579955, 8593907	1	75 61 806
☐ 1	Ignition distributor Engine J088765--	NLS-USE 7481393, 8579955, 8593907	1	75 61 806
☐ 1	Ignition distributor Engine J088765--	EU, ME, SE, US	1	74 81 393
☐ 2	•Distributor cap		1	75 01 216
☐ 3	•Rotor		1	75 64 420
☐ 4	•Cover Part of 75 61 806.		1	75 19 135
☐ 7	•O-ring	NLS-USE 9176470	1	75 19 143
☐ 8	•Regulator		1	75 64 438
☐ 10	•Screw		3	75 19 119
☐ 11	•Screw Part of 75 61 806.		1	75 19 127
☐ 11	•Screw Part of 74 81 393.		1	91 19 561
☐ 12	•Screw		1	75 19 101
☐ 13	•Spring Part of 75 61 806.		1	75 19 085
☐ 13	•Spring Part of 74 81 393.		2	75 19 085
☐ 14	•Spring Part of 75 61 806.		1	93 09 956
☐ 15	•Repair kit Part of 75 61 806.	Goto 3A - 1480	X	75 88 312
☐ 15	•Repair kit		1	83 62 207

Ignition system - Ignition distributor (1990 - 1993), B202I, B212I Also valid for CV 1994




F3350 AAC90

Parts Picklist Notes

Pos	Article	Usage	Qty	Part No.
☐ 1	Ignition distributor		1	74 84 439
☐ 2	• Distributor cap		1	75 01 216
☐ 3	• Rotor		1	75 64 420
☐ 4	• Cover		1	75 19 135
☐ 5	• Spring		2	75 19 085
☐ 6	• Screw		2	75 19 101
☐ 7	• O-ring	NLS-USE 9176470	1	75 19 143
☐ 8	Bracket		1	83 62 287
☐ 9	Screw	1990-1992, NLS-USE 9166323	1	80 82 950


Ignition system - Ignition distributor (1990 - 1993), B202TURBO Also valid for CV 1994



Parts Picklist Notes

Pos	Article	Usage	Qty	Part No.
☐ 1	Ignition distributor		1	74 81 393
☐ 1	Ignition distributor	B202S	1	88 57 617
☐ 1	Ignition distributor	AERO, LHD, US, (SPG)	1	88 57 617
☐ 1	Ignition distributor	185 HP, (137 Kw)	1	88 57 617
☐ 2	• Distributor cap		1	75 01 216
☐ 3	• Spring		2	75 19 085
☐ 4	• Screw		1	75 19 127
☐ 5	• Screw		1	75 19 119
	For distributor 74 81 393.			
☐ 5	• Screw		1	75 19 101
	For distributor 88 57 617.			
☐ 6	• Regulator		1	75 64 438
☐ 7	• Screw		1	91 19 561
	For distributor 74 81 393.			
☐ 7	• Screw		1	75 19 101
	For distributor 88 57 617.			
☐ 8	• O-ring	NLS-USE 9176470	1	75 19 143
☐ 9	Bracket		1	83 62 287
☐ 10	Screw	1990-1992, NLS-USE 9166323	1	80 82 950

Lighting - Headlamp, sealed beam (1990 - 1993) Also valid for CV 1994



Parts Picklist Notes

Pos	Article	Usage	Qty	Part No.
☐ 1	Headlamp	1991-1993, LH	1	40 92 870
☐ 1	Headlamp	1991-1993, RH	1	40 92 888
☐ 2	•Headlamp insert	1991-1993, LH	1	40 93 019
☐ 2	•Headlamp insert	1991-1993, RH	1	40 93 027
☐ 3	••Clamping sleeve		3	95 57 158
☐ 4	•Lock ring		1	95 12 393
☐ 5	•Bulb	40/238 301 006	1	95 12 401
☐ 6	•Attaching frame	LH	1	95 57 075
☐ 6	•Attaching frame	RH	1	95 57 083
☐ 7	•Bushing		1	85 50 840
☐ 8	•Clip		1	85 50 824
☐ 9	Attaching bracket	LH	1	95 56 812
☐ 9	Attaching bracket	RH	1	95 56 820
☒ 10	Screw		4	79 73 159
☐ 11	Screw		2	79 69 223
☐ 12	Nut		2	79 71 658
☐ 13	Protection	LHD, US	2	95 14 811
☐ 14	Bearing sleeve		3	95 12 328

EPC

File Edit View Tools Info Help

English

Vehicle Content Illustration Pick List Search Administration

Lighting - Other lighting (1990 - 1993) Also valid for CV 1994

Parts Picklist Notes

Pos	Article	Usage	Qty	Part No.
☐ 15	•Bulb	40/238 261 002	1	70 84 197
☐ 16	Position lamp	DK, NLS	2	85 61 409
☐ 17	Bulb	40/238 254 007	2	71 54 727
☐ 18	Bracket	DK, LH, NLS	1	85 61 375
☐ 18	Bracket	DK, RH, NLS	1	85 61 383
☐ 19	Nut	DK	2	81 51 235
☐ 20	Side light		2	91 24 132
☐ 20A	•Clip		1	48 30 113
☐ 21	•Bulb socket		1	95 21 857
☐ 22	•Bulb	40/238 300 008	1	95 12 880
☐ 23	•Gasket	NLS-USE 4484259	1	95 12 898
☐ 24	•Seal		1	91 24 140
☒ 25	Lamp	CV	2	98 23 683
☐ 26	Bracket	CV	2	95 97 006
☐ 27	Bulb	CV, 40/238 300 008	2	95 12 880
☐ 28	Clamp	CV	2	98 24 939

Start The... saa... Saa... eBa... EPC 10:10 PM




F3048 AACPO

Pos	Article	Usage	Qty	Part No.
☐ 1	Wiper motor	1991-1993, LH	1	40 95 790
☐ 1	Wiper motor	1991-1993, RH	1	40 95 816
☐ 1	Wiper motor	1991-1993, LHD, US, LH	1	40 93 126
☐ 1	Wiper motor	1991-1993, LHD, US, RH	1	40 93 134
☐ 2	•Contact housing 3-pin, male	Goto 3B - 200	1	95 03 327
☐ 3	Wiper arm	LH	1	95 56 291
☐ 3	Wiper arm	RH	1	95 56 283
☐ 3	Wiper arm	LHD, US, LH	1	95 64 303
☐ 3	Wiper arm	LHD, US, RH	1	95 64 295
☐ 4	•Nozzle	LH	1	95 09 126
☐ 4	•Nozzle	RH	1	95 09 118
☐ 5	•Adapter		1	95 58 149
☐ 5A	•Adapter	LHD, US, LH	1	91 23 217
☐ 5A	•Adapter	LHD, US, RH	1	91 23 225
☐ 6	•Hose	LHD, US, L=130 MM	1	42 54 603
☐ 7	•Junction pipe	LHD, US	1	40 14 783
☐ 8	Wiper blade		2	91 20 882
☐ 9	Nut		2	80 29 548
☐ 10	Washer		2	79 72 284
☐ 11	Bracket		2	95 56 242
☐ 12	Nut		4	79 71 658
☐ 13	Screw	1990-1992	4	80 19 895
☐ 14	...		2	95 51 212

Part No.	Article	Usage
----------	---------	-------

Model			Group		Section		Filter	ON
-------	--	--	-------	--	---------	--	--------	----


Clutch operation - Pedal, master cylinder (1986 - 1989)



Parts Picklist Notes

Pos	Article	Usage	Qty	Part No.
☐ 9	Spring		1	89 35 751
☐ 10	Clutch cylinder		1	89 44 977
☐ 11	• Spring		1	89 86 622
☐ 12	• Spring support		1	89 45 156
☐ 13	• Gasket		1	89 45 248
☐ 14	• Washer		1	89 45 255
☐ 15	• Piston		1	89 45 263
☐ 16	• Gasket		1	89 40 769
☒ 17	• Push rod		1	89 35 371
☐ 18	• Lock ring		1	73 13 232
☐ 19	• Seal		1	73 13 240
☐ 20	Tube clamp		1	79 63 887
☐ 21	Nut	1988-1989	2	81 51 235
☐ 22	Washer		2	79 33 849
☐ 23	Bolt	NLS-USE 4105821	1	89 56 443
☐ 24	Clip		1	82 52 553
☐ 26	Hose	NLS-USE 4385076	1	89 27 139
☐ 26	Hose	1989, ABS, NLS-USE 4385084	1	40 27 801
☐ 27	Clutch hose		1	89 35 124
☐ 28	Clamp		2	73 98 746
☐ 29	Tube clamp		1	83 71 551
☐ 30	Screw		1	79 22 891
☐ 31	Repair kit	Goto 4 - 790	1	89 93 156
☐ 32	Gasket		1	89 41 478

Gearbox - Differential (1990 - 1993) Also valid for CV 1994




Parts Picklist Notes

Pos	Article	Usage	Qty	Part No.
☐ 20	• Shim	0,15MM	X	83 41 612
☐ 20	• Shim	0,30MM	X	83 41 620
☐ 20	• Shim	0,50MM	X	83 41 638
☐ 22	• Screw	1991-1993	11	87 22 548
☐ 23	• Screw	1991-1993	1	87 22 555
☐ 24	• Hydraulic sealant	50 ML	X	74 96 284
☐ 25	• O-ring		2	87 28 156
☐ 30	• Stop ring		1	87 04 421
☐ 31	• Sealing collar	1991-1993	2	87 31 804
☒ 32	• Ball bearing		2	87 04 306
☐ 33	• Retaining ring	M	2	87 28 198
☐ 33	• Retaining ring	1991-1993, A	2	87 28 198
☐ 34	• Washer		1	87 10 360
☐ 35	• Spring		2	87 04 314
☐ 36	• Plunger		2	87 04 322
☐ 37	• Drive gear		1	87 04 413
☐ 38	• Companion flange		2	87 22 472
☐ 44	• Sleeve		1	87 24 866
☐ 45	• O-ring		1	87 11 707
☐ 46	• Gear		1	87 23 900
☐ 47	• Seal		1	87 24 874
☐ 49	• Lock plate		1	87 11 723
☐	• Gasket kit	M Goto 4 - 740	1	74 96 003

EPC
File Edit View Tools Info Help

Vehicle Content Illustration Pick List Search Administration

Gearbox operation - Gear lever (1986 - 1989), M




Parts | Picklist | Notes

Pos	Article	Usage	Qty	Part No.
☐ 5	Knob	5-SPEED	1	75 44 828
☐ 6	Release rod		1	83 33 197
☐ 7	Companion flange		1	93 31 539
15	Contact	Goto 3A - 220		
☐ 16	Catch pin		1	93 48 558
☐ 20	Gear rod		1	75 43 176
☐ 20	Gear rod	5-SPEED	1	75 43 184
☐ 20	Gear rod	5-SPEED	1	75 47 334
☒ 20A	•Bushing		1	83 75 156
☐ 20B	•Plastic bushing		1	83 73 078
☐ 21	Companion flange		1	93 48 665
☐ 22	Spring		1	93 26 380
☐ 23	Pin		1	83 75 024
☐ 24	Spring		1	87 01 385
☐ 25	Bearing shell		1	83 75 990

Start | The Saab ... | saabpics.or... | Saabnet.c... | Books4Car... | **EPC** | 9:47 PM

Gearbox control, manual - Gear lever (1990 - 1993), M Also valid for CV 1994



Parts Picklist Notes


Pos	Article	Usage	Qty	Part No.
☐ 34	Gear	Goto 4 - 680	1	93 37 445
☐ 35	Pin	CA, JP, US	1	93 42 734
☐ 36	Lock ring		2	79 51 353
☐ 37	Washer	1993	1	91 66 372
☐ 38	Pin	NLS-USE 9320987	1	83 78 275
☐ 39	Spring		1	75 42 913
☐ 40	Stay		1	93 42 338
☐ 41	Pin	CA, JP, US	1	93 42 353
☐ 41A	Pin	CA, JP, US	1	93 42 361
☐ 41B	Brace	CA, JP, US, NLS	1	75 49 256
☐ 50	Cover	NLS	1	83 75 339
☒ 51	Screw		2	80 59 487
☐ 51A	Screw	NLS-USE 8059487	1	80 57 697
☐ 52	Nut		3	93 61 163
☐ 53	Lock cylinder		1	82 83 798
☐ 54	Adjusting washer		2	83 74 753

Model SAAB 900 1993

Group 4 Transmission

Section 0350 Filter ON

Gearbox, automatic - Gear selector lever (1986 - 1989), A




Parts Picklist Notes

Pos	Article	Usage	Qty	Part No.
☐ 1	Gear shift housing		1	93 47 816
☐ 2	Gear lever		1	93 49 549
☐ 3	Tube		1	93 01 797
☐ 4	Knob		1	83 17 869
☐ 5	Ring		1	83 38 766
☐ 6	Button		1	93 31 521
☐ 7	Ring		1	83 75 925
☐ 8	Lock nut		1	93 49 564
☐ 9	Contact	Goto 3A - 850		
☐ 10	Screw		3	80 59 420
☐ 11	Washer		3	79 69 975
☐ 12	Spring		1	93 01 631
☐ 13	Needle bearing		1	93 18 197
☐ 15	Catch		1	93 00 211
☐ 16	Pin		2	79 56 105
☐ 17	Cover	NLS	1	83 75 404
☐ 18	Gear	Goto 4 - 820	1	93 20 987
☐ 19	Stay		1	93 42 338
☐ 20	Pin	CA, JP, US	1	93 42 353
☐ 21	Pin		1	93 42 734
☐ 21A	Pin	CA, JP, US	1	93 42 361
☐ 21B	Brace	CA, JP, US, NLS-USE 7549256	1	93 42 346

Ch. -H2020197
Ch. -H3018272


Front wheel brake (1990 - 1993) Also valid for CV 1994



Parts Picklist Notes

Pos	Article	Usage	Qty	Part No.
☐ 5	Pin		2	89 68 588
☐ 7	Screw		4	89 53 283
☐ 8	Screw		2	80 56 160
☐ 9	Nut		2	79 79 511
☐ 10	Brake housing LH		1	91 02 971
	Also available as exchange unit.			
☐ 10	Brake housing RH		1	91 02 989
	Also available as exchange unit.			
☐ 11	• Plug		2	89 55 973
☐ 12	• Bleed screw		2	89 55 072
☐ 13	• Protecting casing		2	89 55 080
☐ 14	• Gasket kit	Goto 5 - 380	2	89 61 799
☐ 15	Retainer		2	89 67 713
☐ 16	• Bellows kit	Goto 5 - 380	1	89 61 807
☐ 17	• Slide pin	NLS-USE 8961807	2	89 55 114
	Not as separate spare part.			
☐ 18	• Protecting casing	NLS	2	89 55 130
	Not as separate spare part.			
☐ 19	• Screw		4	89 55 122
☐ 20	Brake pipe LH		1	91 02 997
☐ 20	Brake pipe RH		1	91 03 037
☐ 21	Bracket LH		1	91 02 856
☐ 21	Bracket RH		1	91 02 864
☐ 22	Screw		2	79 72 441
☐ 23	Brake pad kit		1	89 93 974


Footbrake system - Brake lines ABS - front (1990 - 1993) Also valid for CV 1994



Parts Picklist Notes

Pos	Article	Usage	Qty	Part No.
☐ 22	Pipe bracket		X	89 08 162
☐ 23	Washer		1	79 73 977
☐ 24	Protecting plate		1	91 06 097
☐ 25	Tube clamp		1	91 06 147
☐ 26	Tube clamp		2	91 06 139
☐ 27A	Pipe bracket	1991-1993	3	89 08 162
☐ 28	Clamp		2	89 40 132
☐ 29	Brace		2	89 40 652
☐ 30	Tube clamp		2	89 07 966
☐ 31	Holder	LH	1	91 06 741
☐ 31	Holder	RH	1	91 06 758
☐ 32A	Tensioning band	1991-1993	4	95 28 019
☐ 33	Holder	LH, NLS-USE 9105222	1	91 06 766
☐ 33	Holder	RH, NLS-USE 9105230	1	91 06 774
☐ 34	Sensor	LH	1	40 01 517
☐ 34	Sensor	RH	1	40 01 525
☐ 39	Screw		2	80 21 917
☒ 40	Washer	1993	2	91 66 364
☐ 41	Sleeve		2	89 65 634
☐ 42	Clamp		1	89 31 461
☐ 43	Tube clamp		X	89 65 097
☐ 44	Tube clamp		1	89 59 538
46	Electronic unit	Goto 3A - 920		
47	Brake hose	Goto 5 - 290		

Steering assembly - Steering shaft (1990 - 1993) Also valid for CV 1994




Pos	Article	Usage	Qty	Part No.
☐ 1	Steering shaft		1	40 04 768
☐ 1	Steering shaft	AIR-BAG	1	91 04 647
☐ 2	Column cage		1	89 34 952
☐ 2	Column cage	AIR-BAG	1	91 06 626
☒ 3	Countershaft		1	40 01 798
☐ 4	• Screw		1	73 99 975
☐ 5	• Bellows	1991-1993	1	41 06 993
☐ 6	• Bearing	1991-1993	1	41 06 985
☐ 7	Needle bearing Upper		1	89 35 025
☐ 8	Needle bearing Lower		1	89 36 163
☐ 9	Ground plate		1	89 40 645
☐ 10	Contact ring		1	89 36 411
☐ 11	Retainer		1	89 36 403
☐ 12	Screw		4	89 39 340
☐ 13	Washer	AIR-BAG	1	40 00 360
☐ 14	Bushing	AIR-BAG	1	89 72 374
☐ 15	Lock ring	AIR-BAG	1	89 54 281
☐ 16	Ring	AIR-BAG	1	89 50 172
☐ 17	Ball bearing	AIR-BAG	1	89 50 701
☐ 18	Plate	AIR-BAG	1	91 06 329
☐ 19	Screw	AIR-BAG	1	79 22 347
☐ 20	Washer	LHD	4	89 39 332
☐ 20	Washer	RHD, 4, 8 MM	2	89 39 332

EPC
File Edit View Tools Info Help

Vehicle Content Illustration Pick List Search Administration

Steering assembly - Hydraulic pump (1986 - 1989), B202




Parts Picklist Notes

Pos	Article	Usage	Qty	Part No.
☐ 1	Hydraulic pump	(8991689), NLS-USE 4647442	1	91 01 585
☐ 2	Hose		1	89 42 575
☒ 3	•O-ring	NLS-USE 4104048	2	89 37 500
☐ 4	Delivery pipe	RHD	1	89 40 678
☐ 5	•O-ring	RHD, NLS-USE 4104048	1	89 37 500
☐ 6	Hose	LHD, NLS-USE 4199519	1	89 85 830
☐ 6	Hose	RHD, NLS-USE 4199527	1	89 85 848
☐ 7	•O-ring	NLS-USE 4104048	1	89 37 500
☐ 8	Pulley		1	89 85 947
☐ 9	Junction pipe		1	91 02 559
☐ 10	•O-ring	NLS-USE 4104048	1	89 37 500
☐ 11	Clamp		1	79 69 363
☐ 12	Reservoir	NLS-USE 4197380, 9104555	1	89 86 069
☐ 13	Cover	NLS-USE 4197380	1	89 56 385

Start | The Saab Net... | saabpics.org - ... | Saabnet.com: ... | EPC | 8:47 PM

Steering assembly - Hydraulic pump (1990 - 1993) Also valid for CV 1994




F5448 AAC90

Parts Picklist Notes

Pos	Article	Usage	Qty	Part No.
☐ 1	Hydraulic pump	1991-1993, NLS-USE 4647442	1	41 06 704
☐ 2	Hose		1	89 42 575
☐ 3	•O-ring Ch. L3004088-- Ch. L5000814-- Ch. L7011585--		2	41 04 048
☐ 4	Delivery pipe	RHD	1	89 40 678
☐ 5	•O-ring Ch. L3004088-- Ch. L5000814-- Ch. L7011585--	RHD	1	79 77 580
☐ 6	Hose	1992-1993	1	41 99 519
☐ 6	Hose	1992-1993, RHD	1	41 99 527
☒ 6A	•Filter	1992-1993	1	41 94 445
☐ 6B	•Hose clamp	1992-1993	2	79 70 049
☐ 7	•O-ring Ch. L3004088-- Ch. L5000814-- Ch. L7011585--		1	79 77 580
☐ 8	Pulley		1	89 85 947
☐ 9	Junction pipe		1	91 02 559
☐ 10	•O-ring Ch. L3004088-- Ch. L5000814-- Ch. L7011585--		1	79 77 580
☐ 11	Clamp		1	79 69 363
☐ 12	Reservoir Ch. N2009560-- Ch. N7006306--		1	91 04 555

Steering assembly - Hydraulic pump (1990 - 1993) Also valid for CV 1994



Parts Picklist Notes

Pos	Article	Usage	Qty	Part No.
☐ 17	Screw		1	80 19 911
☐ 18	Lock nut		1	80 73 512
☐ 19	Screw		2	79 74 694
☐ 20	Nut		2	92 23 082
☐ 21	Bracket		1	75 47 482
☐ 22	Screw		3	80 82 935
☐ 23	Screw		1	93 69 844
☐ 24	Nut		1	79 67 953
☐ 25	Washer	1993	1	91 66 372
☐ 26	Screw		1	42 83 198
	Ch. M5007561-- Ch. M70163711-			
☐ 27	Nut		1	80 74 288
☐ 28	Rubber bushing		1	93 65 909
☒ 29	Rubber bushing		1	93 65 917
☐ 30	Sleeve		1	83 56 859
☐ 31	Washer		1	80 73 124
☐ 32	Screw		1	80 82 943
☐ 32	Screw	1993, AC	1	91 66 331
☐ 33	Nut		1	79 67 953
☐ 34	V-belt		1	83 39 921
☐ 35	Hose clamp	RHD	1	79 70 130
☐	Sealing kit hydraulic pump	1991-1993 Goto 6 - 290	X	41 04 766

EPC

File Edit View Tools Info Help

VIN DMS English ?

Vehicle Content Illustration Pick List Search Administration


Rear suspension (1986 - 1989)

Parts Picklist Notes

Pos	Article	Usage	Qty	Part No.
☐ 4	•Screw		2	89 38 466
☐ 5	•Lock nut	1988-1989	2	81 51 482
☐ 6	•Bushing Lower		2	89 39 423
☐ 7	•Bushing Upper	1987-1989	2	91 00 025
☐ 8	•Washer Upper		2	89 85 954
☐ 8A	•Washer Lower		2	89 48 226
☐ 9	•Nut	1988-1989	4	79 79 511
☐ 12	Spacer ring		2	89 33 897
☒ 13	Buffer		2	89 22 445
☐ 14	Spacer	NLS-USE 4107413	2	89 47 152
☐ 15	Washer		2	79 10 599
☐ 16	Screw		2	79 75 063
☐ 17	Spring link	LH	1	89 36 304
☐ 17	Spring link	RH	1	89 47 210
☐ 18	Screw	1986-1988, NLS-USE	2	80 84 410

Start | The Saab Network Chat - ... | TSN Sponsors - Mozilla Fir... | **EPC** | 8:53 PM

Rear suspension (1990 - 1993) Also valid for CV 1994



Parts Picklist Notes

Pos	Article	Usage	Qty	Part No.
☐ 14	Spacer Ch. L3006388-- Ch. L5001599-- Ch. L7016859--		2	41 07 413
☐ 15	Washer		2	79 10 599
☐ 16	Screw Ch. L3006388-- Ch. L5001599-- Ch. L7016859--		2	79 82 812
☐ 17	Spring link	LH	1	89 36 304
☐ 17	Spring link	RH	1	89 47 210
☐ 18	Screw	NLS-USE 7979594	2	79 79 396
☐ 18	Screw	NLS-USE 7982168	2	80 84 451
☐ 18	Screw	Cars with anti-roll bar	2	79 82 168
☐ 19	Lock nut		2	81 51 482
☐ 20	Bearing anchorage	Front.	2	89 47 269
☒ 21	Bushing		2	89 35 298
☐ 22	Nut plate		2	89 89 899
☐ 22A	Rivet		2	79 75 717
☐ 23	Bolt		4	89 90 079
☐ 23A	Washer	NLS-USE 7978067	4	80 30 017
☐ 24	Screw		2	79 82 044
☐ 24	Screw	Cars with anti-roll bar	2	79 82 150
☐ 25	Lock nut		2	81 51 482

EPC
File Edit View Tools Info Help

VIN DMS English ? ?


Vehicle Content Illustration Pick List Search Administration

Rear axle (1986 - 1989)

☐ 1 Rear axle 1986-1987 1 91 00 298
☐ 2 •Bushing 2 89 35 306
☐ 3 •Screw 1986-1987 2 89 28 046
☒ 4 Stay 1986-1987 2 89 44 175
☐ 5 •Bushing 1986-1987 2 89 32 741
☐ 6 •Bushing 1986-1987 2 89 08 675
☐ 7 Washer 1986-1987 2 89 09 632
☐ 8 Screw 1986-1987 2 89 33 293
☐ 8 Screw 1986-1988, (7979172), NLS-USE 7982002 2 80 84 162
☐ 9 Nut 1986-1987 2 79 40 455
☐ 10 Stay 1 89 32 071
☐ 11 •Bushing 1 89 32 014
☐ 12 •Bushing 1 89 30 307
☐ 13 Screw 1 89 42 005
☐ 14 Screw 1 89 30 299
☐ 15 Nut 2 79 40 455
☐ 16 Nut 1986-1987 2 79 63 416

Start | The Saab Network Chat - ... | SAAB 900 79-94 suspensi... | EPC | ScreenPrint 5:46 PM

Rear axle (1990 - 1993) Also valid for CV 1994



Parts Picklist Notes

Pos	Article	Usage	Qty	Part No.
☐ 1	Rear axle		1	91 05 859
☐ 2	•Bushing		2	89 35 306
☐ 3	Screw	NLS-USE 7979586	2	79 79 487
☐ 4	Stay		2	91 03 102
☐ 5	•Bushing		2	89 56 468
☐ 6	•Bushing		2	91 03 110
☐ 7	Washer		2	89 52 277
☐ 8	Screw		2	79 82 002
☐ 9	Lock nut		2	79 77 812
☐ 10	Stay		1	89 32 071
☐ 11	•Bushing		1	89 32 014
☐ 12	•Bushing		1	89 30 307
☐ 13	Screw		1	89 42 005
☐ 14	Screw		1	89 30 299
☐ 15	Nut		2	79 40 455
☐ 16	Lock nut	NLS-USE 7977812	2	80 73 538
☐ 18	Lock nut		2	89 65 360




EPC
File Edit View Tools Info Help

Vehicle Content Illustration Pick List Search Administration

Body shell - Sun roof - Electrically operated (1986 - 1989)

Parts Picklist Notes



Pos Article Usage Qty Part No.


☐ 26	Star washer		4	79 15 549
☐ 28	Rivet		4	92 81 098
☐ 30	Electric motor	NLS-USE 4306007, 7155104, 8019739	1	85 79 211
☐ 31	Bracket		1	76 51 896
☐ 32	Screw		2	82 67 205
☐ 33	Screw		3	92 38 148
☐ 34	Spacer sleeve		3	92 89 604
☐ 35	Clamp		2	71 08 491
☒ 36	Tensioning band		2	79 71 880
☐ 37	Tube clamp		1	83 71 551
☐ 38	Crank		1	92 82 609
☐ 39	Sealing strip		1	92 89 505
☐ 40	Bracket		1	69 17 348
☐ 41	Star washer		4	79 15 549
☐ 42	Screw		23	79 39 804
☐ 43	Bracket		2	82 48 619
☐ 44	Screw	1989	4	80 59 230

Start | The Saab Net... | saabpics.org - ... | Saabnet.com: ... | EPC | 10:21 PM



Vehicle | Content | Illustration | Pick List | Search | Administration

Bonnet, front, wings - Bonnet (1990 - 1993) Also valid for CV 1994



Parts | Picklist | Notes

Pos	Article	Usage	Qty	Part No.
☐ 1	Bonnet		1	69 15 482
☐ 2	• Rib		1	69 15 474
☐ 5	Roller		2	92 37 009
☐ 6	Screw		2	79 71 724
☐ 7	Nut		2	79 71 658
☐ 8	Bonnet hinge		1	82 67 601
☐ 9	Spring	LH	1	40 09 379
☐ 9	Spring	RH	1	40 09 387
☐ 10	Pin		2	82 61 299
☐ 11	Nut		2	79 67 953
☒ 12	Pin		2	73 99 678
Quantity: ± 1				
☐ 13	Screw		2	79 72 144
☐ 14	Buffer	1990-1991, NLS-USE 4304234	2	82 78 343
☐ 15	Bonnet hinge	LH	1	82 66 017
☐ 15	Bonnet hinge	RH	1	82 66 025
☐ 16	Screw		2	80 82 943
☐ 17	Nut	1990-1992	2	80 74 288
☐ 18	Washer		2	79 33 849
☐ 19	Screw		2	82 86 528
☐ 20	Lock pin		1	40 09 627
☐ 21	Washer	NLS-USE 7399835	1	73 11 764
☐ 22	Catch		1	69 26 950
☐ 23	Screw		2	80 59 552

Model SAAB 900 1990


Group 8A Car body, external

Section 0710 Filter ON

Restore ScreenPrint

Exit

Bonnet, front, wings - Bonnet (1990 - 1993) Also valid for CV 1994




Parts Picklist Notes

Pos	Article	Usage	Qty	Part No.
☐ 20	Lock pin		1	40 09 627
☐ 21	Washer	NLS-USE 7399835	1	73 11 764
☐ 22	Catch		1	69 26 950
☐ 23	Screw		2	80 59 552
☐ 24	Lock		1	40 08 421
	Ch. L3007536-- Ch. L7021934--			
☐ 25	Plate		1	40 08 439
	Ch. L3007536-- Ch. L7021934--			
☐ 26	Control cable		1	69 45 521
☐ 26A	•Bushing		1	79 61 311
☐ 27A	Control arm		1	82 78 509
☐ 29A	Screw		3	79 22 891
☒ 30	Spring		1	82 75 877
☐ 31	Cap		1	92 64 508
☐ 32	Screw	1992-1993	2	79 73 001
☐ 33	Clip		1	79 33 443
☐ 34	Screw		2	82 86 296
☐ 37	Guard	RH	1	92 33 487
☐ 37	Guard	LH	1	92 33 495
☐ 38	Rivet		4	79 61 642
☐ 39	Plug		1	82 06 096
☐ 40	Return spring		1	69 73 770
☐ 41	Washer		1	69 73 762



Doors, boot lid - Door - Window lift (1990 - 1993), 3CK, 2SN




Parts Picklist Notes

Pos	Article	Usage	Qty	Part No.
☐ 14	•Lever	RH	1	82 07 581
☐ 14A	•Pin		2	82 06 476
☐ 15	•Compression spring		2	82 06 369
☐ 16	Screw		12	79 75 212
☐ 17	Screw	NLS-USE 6937361	12	69 13 784
☐ 19	Plug		2	70 38 342
☐ 20	Window lift	LH	1	92 92 855
☐ 20	Window lift	RH	1	92 92 863
☐ 21	Window lift Electrically operated	LH	1	92 87 038
☐ 21	Window lift Electrically operated	RH	1	92 87 046
☐ 22	•Motor	LH	1	85 67 638
☐ 22	•Motor	RH	1	85 67 646
☐ 22A	•Window lift Electrically operated	LH	1	92 87 012
☐ 22A	•Window lift Electrically operated	RH	1	92 87 020
☐ 23	•Protection	LH	1	85 98 047
☐ 23	•Protection	RH	1	85 98 260
☐ 25	Screw	1990-1992	8	80 19 895
☐ 26	Washer		8	73 99 819
☐ 28	Washer		4	79 10 540
☐ 29	Crank		2	94 45 651
☐ 30	Cover		2	84 76 301



Vehicle | Content | Illustration | Pick List | Search | Administration

External details - Air vent, decor - rear door (1986 - 1989)



Parts | Picklist | Notes


Pos	Article	Usage	Qty	Part No.
☐ 11	Nut		4	79 73 365
☐ 12	Air outlet	SN, LH, NLS-USE 6941777, 6941793	1	92 89 877
	Ch. -J3019110 Ch. -J7026611			
☐ 12	Air outlet	SN, RH, NLS-USE 6941785, 6941793	1	92 89 885
	Ch. -J3019110 Ch. -J7026611			
☐ 13	• Sealing strip	SN, LH	1	92 27 539
☐ 13	• Sealing strip	SN, RH	1	92 27 547
☐ 14	Clip	SN, NLS-USE 4013165	8	92 36 589
☐ 15	Screw	SN	8	79 22 230
☐ 16	Cover	SN	8	92 85 404
	Ch. -J3019110 Ch. -J7026611			
☐ 17	Protection	CK, LH, NLS-USE 6947451	1	92 37 512
	Ch. -J3019474 Ch. -J7027362			
☐ 17	Protection	CK, RH, NLS-USE 6947469	1	92 37 520
	Ch. -J3019474 Ch. -J7027362			
☐ 17	Decor	SN, LH, NLS-USE 6947436	1	92 34 535
	Ch. -J3019474 Ch. -J7027362			
☐ 17	Decor	SN, RH, NLS-USE 6947444	1	92 34 543
	Ch. -J3019474 Ch. -J7027362			

Model SAAB 900 1986

Group 8A Car body, external

Section 1150 Filter ON


External details - Convertible (1986 - 1989), CV



Parts Picklist Notes

Pos	Article	Usage	Qty	Part No.
☐ 21	Holder	LH	1	69 50 398
☐ 21	Holder	RH	1	69 50 380
☐ 22	Sealing strip	LH	1	69 50 323
☐ 22	Sealing strip	RH	1	69 50 315
☐ 23	Decor strip	LH	1	69 33 261
☐ 23	Decor strip	RH	1	69 33 279
☐ 24	Guide moulding	LH	1	69 32 461
☐ 24	Guide moulding	Rear. Ch. -K7021109		
☐ 24	Guide moulding	RH	1	69 32 479
☐ 24	Guide moulding	Rear. Ch. -K7021109		
☐ 25	Decor strip	LH	1	69 33 436
☐ 25	Decor strip	RH	1	69 33 444
☐ 25	Decor strip	Ch. -K7021109		
☐ 26	Seal		2	69 33 170
☐ 26	Seal	Ch. -K7021109		
☐ 27	Strip		2	69 33 337
☐ 27	Strip	Rear.		
☐ 28	Strip	LH, NLS-USE 6999825	1	69 33 352
☐ 28	Strip	Front.		
☐ 28	Strip	RH, NLS-USE 6999825	1	69 34 152
☐ 28	Strip	Front.		
☐ 29	Seal		2	69 34 079
☐ 30	Seal	NLS-USE 6996821	2	69 33 154
☐ 31	Stop	NLS-USE 6996961	2	69 35 845
☐ 31	Stop	Front. Ch. -K7021109		

External details - Convertible (1986 - 1989), CV



Parts Picklist Notes

Pos	Article	Usage	Qty	Part No.
☐ 22	Sealing strip	LH	1	69 50 323
☐ 22	Sealing strip	RH	1	69 50 315
☐ 23	Decor strip	LH	1	69 33 261
☐ 23	Decor strip	RH	1	69 33 279
☐ 24	Guide moulding	LH	1	69 32 461
☐ 24	Guide moulding	RH	1	69 32 479
☐ 25	Decor strip	LH	1	69 33 436
☐ 25	Decor strip	RH	1	69 33 444
☒ 26	Seal		2	69 33 170
☐ 27	Strip		2	69 33 337
☐ 28	Strip	LH, NLS-USE 6999825	1	69 33 352
☐ 28	Strip	RH, NLS-USE 6999825	1	69 34 152
☐ 29	Seal		2	69 34 079
☐ 30	Seal	NLS-USE 6996821	2	69 33 154
☐ 31	Stop	NLS-USE 6996961	2	69 35 845
☐ 32	Stop	NLS-USE 6996953	2	69 35 571




Pos	Article	Usage	Qty	Part No.
☐ 1	Seat belt Ch. --L3000081 Ch. --L5000002 Ch. --L7000105	2SN, 3CK, LH	1	96 82 139
☐ 1	Seat belt Ch. --L3000081 Ch. --L5000002 Ch. --L7000105	2SN, 3CK, RH, NLS-USE 4077624, 4080453	1	96 82 147
☐ 1	Seat belt Ch. L3000082-- Ch. L5000003-- Ch. L7000106--	1990, 2SN, 3CK, LH, NLS-USE 4080446	1	40 77 665
☐ 1	Seat belt Ch. L3000082-- Ch. L5000003-- Ch. L7000106--	1990, 2SN, 3CK, RH	1	40 77 673
☐ 1	Seat belt	1990, CV, LH, NLS-USE 4166716	1	96 49 658
☐ 1	Seat belt	1990, CV, RH, NLS-USE 4166724	1	96 49 666
☐ 2	•Washer	CV	1	40 77 509
☐ 3	•Bearing sleeve	NLS	1	94 22 346
☐ 3A	•Button		1	96 17 846
☐ 3B	•Button		1	96 17 853
☐ 4	Screw	2SN, 3CK	2	84 99 204
☐ 4	•Screw	CV	1	84 99 238
☐ 5	Screw	2SN, 3CK	2	96 81 735



Pos	Article	Usage	Qty	Part No.
☐ 1	Seat belt	3CK, 2SN, LH	1	94 70 394
☐ 1	Seat belt	3CK, 2SN, RH	1	94 70 410
☐ 1	Seat belt	CV, LH, NLS-USE 4077616, 4166716	1	98 82 291
☐ 1	Seat belt	CV, RH, NLS-USE 4077624, 4166724	1	98 82 309
☐ 3	•Bearing sleeve	NLS	2	94 22 346
☐ 4	Screw	2SN, 3CK	2	84 99 204
☐ 4	•Screw	CV	1	84 99 204
☐ 5	Screw	2SN, 3CK	2	96 81 735
	Ch. J3009727--			
☐ 5	•Screw	CV	1	84 99 204
☐ 6	Screw		2	94 85 020
☐ 8	Belt catch	1987-1989, LH	1	96 11 724
☐ 8	Belt catch	1987-1989, RH	1	96 11 732
☐ 8	Belt catch	1989, RHD, JP, LH FOR	1	96 11 732
☐ 8	Belt catch	1987-1989, CA, JP, US, RH	1	96 11 740
☐ 8	Belt catch	1987-1989, AU, LH, NLS-USE 9611724	1	97 24 071
☐ 8	Belt catch	1987-1989, AU, RH, NLS-USE 9611732	1	97 24 089
☐ 9	Screw		2	84 99 204
☐ 11	Cover		2	94 85 657
☐ 12	Screw		4	84 10 961


Other interior equipment - Seat belt, front seat - Automatic (1986 - 1989), 3CK, US



Parts Picklist Notes

Pos	Article	Usage	Qty	Part No.
☐ 6	Support Driver seat	RH	1	98 62 889
☐ 6	Support Passenger seat		2	98 62 913
☐ 7	Blind rivet nut		6	73 98 860
☐ 8	Screw		6	80 59 263
☐ 9	Screw		4	80 59 545
☐ 10	Screw		4	79 78 075
☐ 11	Washer Driver seat		2	98 62 939
☐ 12	Washer Passenger seat		2	98 63 259
☐ 13	Screw		6	98 63 838
☐ 14	Screw		2	98 64 372
☐ 15	Rivet		4	79 68 878
☐ 16	Lock tab Normally placed in toolbox	LH	1	96 70 027
☐ 16	Lock tab Normally placed in toolbox	RH	1	96 11 773
☐ 17	Washer Driver seat		2	79 78 067
☐ 18	Washer Passenger seat	1988-1989	4	79 16 513
☐ 19	Cover		4	96 60 192
☐ 20	Clamp		6	98 79 206
☐ 21	Screw		2	79 73 951
☐ 22	Clip		2	85 30 917

Heating and ventilation - AC evaporator - Sanden (1986 - 1989)



Parts Picklist Notes

Pos	Article	Usage	Qty	Part No.
☐ 1	Hose	C	1	94 81 540
☐ 1	Hose	1987-1989, C	1	94 82 019
	For cars with integrated bumpers			
☐ 2	•O-ring	NLS-USE 4318036	1	79 72 094
☒ 3	Condenser	1986-1988, NLS-USE 4382396	1	94 01 951
☐ 4	Screw		2	80 59 578
☐ 5	Screw		2	79 22 420
☐ 6	Washer		2	80 29 951
☐ 7	Tube	1987-1989	1	94 82 035
	For cars with integrated bumpers			
☐ 8	Hose	1987-1989	1	94 82 027
	For cars with integrated bumpers			
☐ 9	•O-ring	NLS-USE 4318028	4	79 72 086
☐ 10	Clamp		1	94 81 458
☐ 10A	Spacer		1	94 81 441
☐ 10B	Stay pad		1	94 81 664
☐ 11	Screw		1	80 19 911
☐ 12	Nut	1988-1989	1	81 51 227
☐ 13	Reservoir	1987-1989, NLS-USE 4383550	1	94 82 068
	For cars with integrated bumpers			
☐ 14	•Contact		1	94 80 005
☐ 15	•O-ring	NLS-USE 4073979	1	94 73 851
☐ 18	Nut	1988-1989	1	81 51 235
☐ 19	Evaporator		1	94 80 955

EPC
File Edit View Tools Info Help

VIN DMS English ?

Vehicle Content Illustration Pick List Search Administration

Heating and ventilation - AC compressor (1990 - 1993), B202, B212 Also valid for CV 1994

Parts Picklist Notes

Pos	Article	Usage	Qty	Part No.
☐ 1	Compressor	1991-1993	1	40 71 718
	Converted AC-system	Goto 8C - 410		
☐ 2	• Seal		1	94 82 217
☐ 2A	• Switch		1	94 81 995
☐ 2B	• Valve		1	94 82 225
☐ 2D	• O-ring		2	79 72 318
☐ 3	• Plug	NLS	1	94 82 209
☐ 4	• Clutch Ch. L3007202-- Ch. L5002594-- Ch. L7021119--		1	40 73 227
☐ 5	• Valve		1	40 70 835
☐ 6	• Valve		1	40 71 411
☐ 7	• Plug Brown		1	40 71 593
☐ 8	• Plug Black		1	40 71 585
☐ 10	Bracket	1991-1993	1	41 18 774
☐ 11	Screw		2	80 98 113

Start | The Saab Net... | saabpics.org - ... | Yahoo! - Mozill... | EPC | 7:14 PM

EPC
File Edit View Tools Info Help

VIN DMS English ?

Vehicle Content Illustration Pick List Search Administration


Heating and ventilation - AC compressor (1990 - 1993), B202, B212 Also valid for CV 1994

Parts Picklist Notes

Pos	Article	Usage	Qty	Part No.
☐ 10	Bracket	1991-1993	1	41 18 774
☐ 11	Screw		2	80 98 113
☐ 12	Screw		1	93 39 615
☐ 13	Screw		4	79 75 030
☐ 14	Washer		4	80 73 108
☐ 15	Nut		4	79 67 979
☐ 16	Sleeve		2	83 56 859
☐ 17A	Pulley Ch. M5009668- Ch. M7016371-		1	41 18 964
☒ 17B	Tensioning arm Ch. M5009668- Ch. M7016371-		1	41 19 780
☐ 17C	Washer Ch. M5009668- Ch. M7016371-		1	80 73 108
☐ 17D	Lock screw Ch. M5009668- Ch. M7016371-		1	93 45 232
☐ 18	Screw	1993	1	91 66 331


Start | The Saab Network ... | saabpics.org - Welc... | Yahoo! - Mozilla Fire... | EPC | 7:17 PM

Fuel system - Fuel tank (1990 - 1993)




Parts Picklist Notes

Pos	Article	Usage	Qty	Part No.
☐ 10	Fuel pipe VIN P1001544-, See pos 6A. Ch. -P1001543		1	40 17 455
☐ 10	Fuel pipe VIN P1013124-, See pos 6A. Ch. P1001544- Ch. -P1013123	ME	1	41 63 200
☐ 10	Fuel pipe	BR	1	41 63 200
☐ 11	Fuel pipe VIN P1001544-, See pos 9A. Ch. -P1001543		1	75 91 274
☐ 11	Fuel pipe VIN P1013124-, See pos 9A. Ch. P1001544- Ch. -P1013123	ME	1	41 63 218
☐ 11	Fuel pipe	BR	1	41 63 218
☒ 12	•Non-return valve		1	89 77 779
☐ 13	•Valve peg		1	89 77 761
☐ 14	•O-ring		2	79 74 546
☐ 15	Tube VIN P1001544-, See pos 6A + 9A. Ch. -P1001543		1	89 78 934
☐ 15	Tube VIN P1013124-, See pos 6A + 9A. Ch. P1001544- Ch. -P1013123	ME	1	41 63 234
☐ 15	Tube	BR	1	41 63 234
☐ 16	Fuel filter	1992-1993	1	41 63 853



Battery - Battery (1990 - 1993)



Parts Picklist Notes

Pos	Article	Usage	Qty	Part No.
	Battery See accessories catalogue			
☐ 1	Battery shelf	1992-1993	1	42 93 619
☐ 1A	Protecting moulding	NLS-USE 8564973	1	84 97 471
	Part of 40 09 429.			
☒ 2	Brace		1	95 15 222
☐ 3	Screw		1	79 77 499
☐ 4	Screw		4	79 75 451
☐ 5	Cable	+	1	95 24 208
☐ 6	Cable	-	1	51 01 167
	Ch. L1010360-- Ch. L2007967--			
☐ 7	Bracket		1	40 61 891
☐ 8	Screw	NLS-USE 7922891	2	79 74 769
☐ 9	Casing		1	95 03 053
☐ 10	Stud		2	94 46 881
☐ 11	Nut		2	79 71 658

EPC

File Edit View Tools Info Help

English

Vehicle Content Illustration Pick List Search Administration

Gearbox control, manual - Gear lever (1994 - 1998), M

23

24

26

27

28

29

30

31

31A

32

34

35

36

Parts Picklist Notes

Pos	Article	Usage	Qty	Part No.
☐ 29	•Lock nut Ch. -R1025663		4	80 73 512
☐ 30	Clamp Ch. -R1025663		1	93 48 533
☐ 30	•Clamp Ch. R1025664-		1	44 77 139
☐ 31	Screw Ch. -R1025663		1	75 41 907
☐ 31	•Screw Ch. R1025664-		1	40 87 813
☐ 31A	Washer Ch. -R1025663		1	91 66 372
☐ 31A	•Washer Ch. R1025664-		1	80 29 985
☐ 32	•Nut		1	79 75 501
☒ 34	Pin Ch. -V1031919	1994-1997	1	83 75 172
☐ 35	Washer		1	80 29 944
☐ 36	Nut Ch. -V1031919	1994-1997	1	83 35 002

Start The Saab Netw... EPC 9:02 PM

File Edit View Tools Info Help

VIN DMS English ?


Vehicle Content Illustration Pick List Search Administration

Doors, boot lid - Door lock - Front door (1990 - 1993)

Parts Picklist Notes

Pos	Article	Usage	Qty	Part No.
☐ 20	Rivet		2	97 76 139
☐ 21	Return spring	LH	1	97 76 188
☐ 21	Return spring	RH	1	97 76 105
☐ 23	Nut		2	97 76 121
☐ 24	Clamp		2	97 82 566
☐ 25	Screw		4	80 59 396
☐ 26	Cage nut		4	79 74 231
☐ 27	Lock button		2	40 37 735
☐ 28	Bushing	1990-1991, NLS-USE 4269957	2	97 62 048
☐ 29	Attaching plate	LH	1	95 78 808
☐ 29	Attaching plate	RH	1	95 78 790
☐ 30	Screw		2	79 65 684
☐ 31	Cover washer	EM	1	97 58 186
☐ 31	Cover washer		2	97 58 186
☐ 32	Rivet		4	95 08 094
☐ 33	Washer		2	95 78 386

Upholstery - Headlining, pillar trim (1994 - 1998)



Pos	Article	Usage	Qty	Part No.
☐ 1	Head lining	5CS	1	42 73 660
☐ 1	Head lining	1994-1997, 4D	1	42 73 652
☐ 1	Head lining	5CS, SR	1	42 73 645
☐ 1	Head lining	1994-1997, 4D, SR	1	42 73 637
☐ 1A	•Protection		1	97 56 974
☐ 2	Upholstery clip		1	97 85 031
☐ 3	Strip	SR	1	96 63 907
☐ 4	Crash pad Ch. --S1003494	LH, NLS-USE 4608105	1	42 73 579
☐ 4	Crash pad Ch. --S1003494	RH, NLS-USE 4608113	1	42 73 587
☐ 4	Crash pad Ch. S1003495--	LH	1	46 08 105
☐ 4	Crash pad Ch. S1003495--	RH	1	46 08 113
☐ 4A	•Clip Ch. --S1019676		2	95 48 389
☐ 4A	•Clip Ch. S1019677--		3	95 48 389
☐ 4B	•Clip Ch. --S1019676		1	97 50 753
☐ 5	Crash pad Light beige	LH	1	44 86 585
☐ 5	Crash pad Light beige	RH	1	44 86 593
☐ 5	Crash pad Light beige	1994-1995, LH	1	44 86 643

EPC
File Edit View Tools Info Help

Vehicle Content Illustration Pick List Search Administration

Short block - Cylinder head (1994 - 1998), 4-CYL


Parts Picklist Notes

Pos	Article	Usage	Qty	Part No.
☐ 1	Cylinder head	1995-1998, NLS-USE 9182205, 9182304	1	91 48 693
	Also available as exchange unit. Engine --V002172			
☐ 1	Cylinder head		1	91 82 304
	Also available as exchange unit. Engine V002173--			
☐ 2	•Cylinder head		1	91 47 927
	Engine --V002172			
☐ 2	•Cylinder head		1	91 85 208
	Engine V002173--			
☐ 2A	••Guide sleeve		2	75 04 566
☐ 2B	••Screw		2	75 04 178
☐ 3	••Seal		16	75 00 713
☐ 4	••Screw		8	75 85 847
☐ 5	••Sealing washer		2	75 88 320
☐ 6	••Screw	1995-1998	12	40 87 805
☐ 7	••Plug	1994-1997	3	81 23 143
☐ 8	••Valve guide	1994-1996	16	91 66 240
☐ 8	Valve guide	1994-1996	X	91 66 265

Start | Yahoo! - Mozill... | Saabnet.com ... | The Saab Net... | EPC

6:16 PM

Fuel system - Fuel tank (1994 - 1998)



Parts Picklist Notes


Pos	Article	Usage	Qty	Part No.
☐ 4	Hose		1	44 40 244
☐ 5	Hose	1994-1995	1	42 36 238
☒ 6	Hose clamp		1	45 26 836
	Quantity: ± 1			
☐ 7	Hose clamp	1994-1995	1	44 41 697
☐ 12	Hose	1994-1995	1	43 94 268
☐ 13	Hose clamp	1994-1995	4	79 73 605
☐ 14	Tensioning band		2	42 35 040
☒ 15	Nut		1	79 71 922
☐ 16	Nipple	1994-1995	1	42 29 332
☐ 17	Screw	1994-1997	1	42 26 023
☐ 18	Sealing collar		1	42 27 294
☐ 19	Hose clamp	1994-1995	1	44 41 689
☐ 20	Filler cap	CV	1	43 91 058
☐ 20	Filler cap	1995, 3D, 5D	1	43 97 048
☐ 20	Filler cap	1995, CV	1	43 97 048

Model SAAB 900 1995

Group 2 Engine

Section 0840 Filter ON


Cooling system - Cooling system (1994 - 1997), 6-CYL



Parts Picklist Notes

Pos	Article	Usage	Qty	Part No.
☐ 1	Radiator	1994-1997, M	1	42 83 438
☐ 1	Radiator	1994-1997, M, AC, ACC	1	43 57 927
☐ 1	Radiator	1994-1997, A, NLS-USE 4729596	1	43 57 794
☐ 1A	•Draining plug		1	43 56 408
☐ 1B	•O-ring		1	43 56 416
☐ 2	Rubber bushing	1994-1995	2	42 83 594
☐ 3	Rubber bushing	1994-1995	2	42 83 321
☐ 4	Clip		2	42 83 586
☐ 6	Air shield		1	42 83 347
☐ 7	Air shield		1	42 83 453
☐ 8	Radiator hose	1994, 3D, 5D, NLS-USE 4876280	1	43 57 752
☐ 8	Radiator hose	CV, NLS-USE 4876280	1	43 57 752
☐ 8	Radiator hose	1994, 3D, 5D, NLS-USE 4876280	1	43 95 042
☐ 8	Radiator hose	For tropical market; ME, LA, AU, HK, SG, TH, CY Ch. --S7009999	1	43 95 042
☐ 9	Radiator hose	1994, 3D, 5D, NLS-USE 4876298	1	43 57 760
☐ 9	Radiator hose	CV, NLS-USE 4876298	1	43 57 760
☐ 9	Radiator hose	1994, 3D, 5D, NLS-USE 4876298	1	43 95 059

Supercharging system - Turbocharger (1994 - 1998), TURBO



Parts Picklist Notes


Pos	Article	Usage	Qty	Part No.
☐ 1	Turbocharger Also available as exchange unit.		1	91 46 010
☐ 2	•Nipple		1	91 69 517
☐ 3	•Nut		1	91 69 426
☐ 4	•Wastegate		1	91 69 434
☐ 10	Tube Engine -V059179		1	91 43 819
☐ 10	Tube Engine V059180-		1	91 80 480
☐ 11	Screw	1996-1998	2	79 78 117
☐ 12	O-ring		1	91 47 844
☐ 13	Nut		1	91 16 674
☐ 14	Gasket		1	91 13 937
☐ 15	Screw		7	93 57 138
☐ 16	Stay		1	91 46 150
☐ 17	Screw	NLS-USE 7978075	2	80 59 768
☐ 18	Sealing kit	1994-1996	X	88 18 569

Model SAAB 900 1996

Group 2 Engine

Section 2070 Filter ON

Supercharging system - Turbocharger (1994 - 1998), TURBO



Parts Picklist Notes


Pos	Article	Usage	Qty	Part No.
☐ 14	Gasket		1	91 13 937
☐ 15	Screw		7	93 57 138
☐ 16	Stay		1	91 46 150
☐ 17	Screw	NLS-USE 7978075	2	80 59 768
☐ 18	Sealing kit	1994-1996 Goto 2 - 2160	X	88 18 569
☐ 19	Hose		1	42 28 532
☐ 20	Hose clamp		1	79 70 148
☐ 21	Hose		1	44 44 253
☐ 22	Hose clamp		4	79 70 098
☐ 23	Charge air bypass valve		1	43 91 157
☐ 24	Hose		1	44 44 261
☐ 25	Clamp		1	73 98 407
☐ 26	Tensioning band		1	73 98 977
27	Air cleaner	Goto 2 - 780		
28	Hose	Goto 2 - 1800		

Model SAAB 900 1996

Group 2 Engine

Section 2070 Filter ON

Wiring and fuses - Instrument (1994 - 1995)



Parts Picklist Notes

Pos	Article	Usage	Qty	Part No.
☐ 15	Instrument Ch. S2018152--	TURBO, MPH	1	46 17 643
☐ 16	•Casing		1	44 88 532
☒ 17	•Bulb instrument lighting green		7	40 87 383
☐ 18	•Bulb warning lamp black		24	40 87 409
☐ 19	•Bulb charging indicator lamp blue		1	40 87 425
☐ 20	Odometer		1	44 88 540
☐ 21	•Bulb		2	40 87 441
☐ 22	•Bulb socket grey		2	40 87 565
☐ 23	Rear section State VIN and mileage. State whether the speedometer is graduated in km/h or in mph. Ch -R2015979, I KM/H. Ch -R2015392, I MPH.	I	1	44 88 557
☐ 23	Rear section Ch R2015980--, I KM/H. Ch R2015393--, I MPH. Programmed using a TECH 2 Scan Tool. Ch -S2016982, --S7013676, I KM/H. Ch -S2014196, --S7014997, I MPH.	I, NLS-USE 4711214	1	45 19 963
☐ 23	Rear section Ch -S2014973, --S7013367, TURBO KM/H. Ch --S2018151, TURBO MPH.	TURBO, NLS-USE 4711214	1	45 19 963
☐ 23	Rear section Programmed using a TECH 2 Scan Tool.	NLS-USE 4711214	1	46 17 619

File Edit View Tools Info Help

VIN DMS

English

Vehicle Content Illustration Pick List Search Administration

Gearbox control, manual - Gear rod (1994 - 1998), M

Parts Picklist Notes

Pos	Article	Usage	Qty	Part No.
☐ 1	Bellows	1994-1996	1	42 82 323
☐ 2	Linkage	1994-1996	1	42 82 307
☐ 3	•Cone fitting	1994-1996	1	42 82 372
☐ 4	•Screw	1994-1996	1	75 41 907
☐ 5	•Washer	1994-1996	1	80 29 985
☐ 6	•Nut	1994-1996	1	79 75 501
☐ 7	•Clamp	1994-1996	1	93 48 533
☐ 8	Gaiter		1	42 82 331
☐ 9	Bushing	1994-1996	1	43 87 361
☐ 10	Screw		1	79 78 190
☐ 11	Gear rod	B206I	1	44 91 262
☐ 11	Gear rod		1	42 82 166
☐ 20	Retaining ring	1994-1996	1	46 85 806


F8E36 AAC04

Start

Th... sa... Ya... Sa... Sa... E...

8:16 PM

Gearbox - Differential (1994 - 1998)




F4868 AAC94

Parts Picklist Notes

Pos	Article	Usage	Qty	Part No.
☐ 5A	•Washer Not as separate spare part.	M	2	87 41 332
☐ 6	•Differential shaft Not as separate spare part.	1997-1998, M	1	87 47 255
☐ 7	•Roll pin Not as separate spare part. Not applicable to gearboxes having a serial number beginning with "M". Gear box -N55112	M	1	81 17 863
☐ 7	•Roll pin Not as separate spare part. Applicable to gearboxes having a serial number beginning with "M". Gear box N55113--	M	1	79 18 584
☒ 8	•Roller bearing	M	2	87 34 568
☐ 9	•Gear	B206I, M, FM 54501	1	87 30 715
☐ 9	•Gear	B206I, B204I, M, FM51501	1	87 30 285
	Not applicable to gearboxes having a serial number beginning with "M". Gear box -N55112			
☐ 9	•Gear	B204I, M, FM51501	1	87 44 518
	Applicable to gearboxes having a serial number beginning with "M". Gear box N55113--			
☐ 9	•Gear	B234I, M	1	87 30 715
	Not applicable to gearboxes having a serial number beginning with "M". Gear box -N55112			
☐ 9	•Gear	1996-1998, B258I, M	1	87 30 715
	Not applicable to gearboxes having a serial number beginning with "M". Gear box -N55112			
☐ 9	•Gear	B234I, B258I, M	1	87 44 492
	Not applicable to gearboxes having a serial number beginning with "M". Gear box N55113-- Gear box -N58100			




Front suspension (1994 - 1996)




Parts Picklist Notes

Pos	Article	Usage	Qty	Part No.
☐ 3	Spring strut insert yellow With lowered chassis See foreword Ch. T7000157--	CV, Marked: E	2	46 46 493
☐ 4	Sleeve		2	42 43 390
☐ 5	Bump stop		2	44 83 897
☐ 6	Support		2	42 45 734
☐ 7	Spring support Ch. S2038208-- Ch. S7021922--		2	45 44 979
☐ 8	Thrust bearing		2	42 46 377
☐ 9	Washer Ch. S2038208-- Ch. S7021922--		2	49 07 663
☐ 10	Support bearing Ch. S2038208-- Ch. S7021922--		2	45 44 276
☐ 11	Washer Ch. S2038208-- Ch. S7021922--		2	46 46 634
☐ 12	Hexagon nut (4345484)		2	43 46 862
☐ 13	Nut		6	79 79 602
☐ 14	Washer		2	79 16 497
☐ 15	Spacer		2	46 89 378
☐ 20	Anti-roll bar Also applies to modified cars with a lower VIN. Ch. S2012272-- Ch. S7014773--	3D, 5D	1	45 43 492



Pos	Article	Usage	Qty	Part No.
☐ 1	Top stack	NLS-USE 4857173	1	45 56 486
☐ 2	•Bow	BDW No1	1	45 56 411
☐ 3	••Lock	1994-1995, LH, NLS-USE 4698213	1	44 94 811
☐ 3	••Lock	1994-1995, RH, NLS-USE 4698221	1	44 94 829
☐ 3A	•••Screw		2	48 59 781
☐ 3B	•••Hook	1994-1995	2	45 56 494
☐ 3C	•••Extension	1994-1995	2	45 56 502
☐ 4	••Locating pin		2	47 66 895
☐ 4A	••Nut		1	48 59 799
☐ 4B	••Pocket		1	48 59 765
☐ 4C	••Screw		2	79 74 421
☐ 4D	••Sealing profile		1	49 01 393
☐ 5	•Bow	BDW No2, NLS-USE 4850749	1	46 97 223
☐ 5A	••Link arm	LH	1	46 97 280
☐ 5A	••Link arm	RH	1	46 96 811

External details - Decor (1994 - 1998), 5D




F6014 AAC94

Parts Picklist Notes

Pos	Article	Usage	Qty	Part No.
☐ 1	Decor strip	LH	1	42 40 958
☐ 1	Decor strip	RH	1	42 40 966
☐ 2	•Bushing		2	44 69 854
☐ 3	Decor strip	LH	1	42 41 014
☐ 3	Decor strip	RH	1	42 41 022
☐ 4	•Clip		6	42 45 957
☐ 5	•Bushing		7	44 69 854
☐ 6	Decor strip	LH	1	42 40 974
☐ 6	Decor strip	RH	1	42 40 982
☐ 7	•Clip		3	42 45 957
☐ 8	•Bushing		4	44 69 854
☐ 9	•Bushing		1	44 69 862
☐ 10	Decor strip	LH	1	42 40 990
☐ 10	Decor strip	RH	1	42 41 006
☐ 11	Bushing		4	73 73 269
☐ 12	Sill protection	LH	1	42 40 156
☐ 12	Sill protection	RH	1	42 40 164
☐ 13	Sill protection	LH	1	42 40 172
☐ 13	Sill protection	RH	1	42 40 180
☐ 14	Plastic nut		14	40 87 128

External details - Spoiler (1994 - 1998)




Parts Picklist Notes

Pos	Article	Usage	Qty	Part No.
☐ 1	Spoiler Ch. --S2001487 Ch. --S7011160	LH, NLS-USE 4522694	1	43 98 491
☐ 1	Spoiler Ch. S2001488-- Ch. S7011161--	LH	1	45 22 694
☐ 2	•Nut		2	90 87 040
☐ 3	Spoiler Ch. --S2001487 Ch. --S7011160	RH, NLS-USE 4522702	1	43 98 509
☐ 3	Spoiler Ch. S2001488-- Ch. S7011161--	RH	1	45 22 702
☐ 4	•Nut		1	90 87 040
☐ 5	•Cover Ch. --S2001487 Ch. --S7011160		1	42 48 720
☐ 5	Cover Ch. S2001488-- Ch. S7011161--		1	42 48 720
☐ 6	Screw		3	79 82 325
☐ 7	Air shield Ch. --S2001487 Ch. --S7011160	LH	1	43 34 470
☐	•Clip nut		4	79 67 995
☐ 7	Air shield Ch. S2001488-- Ch. S7011161--	LH	1	42 96 174
☐	•Clip nut		2	79 67 995



External details - Door mirrors (1994 - 1998)



Parts Picklist Notes

Pos	Article	Usage	Qty	Part No.
☐ 8	• Mirror glass Ch. T7012504-- Ch. V2002557--	RHD, AU, RH, FLAT	1	48 18 118
☐ 9	• Cover	LH	1	43 89 854
☐ 9	• Cover	RH	1	43 89 862
☐ 9	• Cover Paintable design	LH	1	48 88 186
☐ 9	• Cover Paintable design	RH	1	48 88 194
☐ 10	Screw		3	79 78 422
☐ 11	Cover	3D, 5D, LH	1	42 30 827
☐ 11	Cover	3D, 5D, RH	1	42 15 364
☐ 11	Cover	CV, LH	1	45 51 040
☐ 11	Cover	CV, RH	1	45 51 057
☐ 12	Cover		2	43 89 235
☐ 13	Rivet	CV	4	43 45 872

Model SAAB 900 1998

Group 8A Car body, external

Section 1440 Filter ON

File Edit View Tools Info Help

VIN DMS English

Vehicle Content Illustration Pick List Search Administration

Dashboard - Panel - Instrument plate (1994 - 1998)

7730H AAC24

Parts Picklist Notes

Pos	Article	Usage	Qty	Part No.
☐ 1	Instrument panel	LHD, AIRBAG 1, NLS-USE 4609566	1	42 19 192
	Ch. --S2016099, --S7015187, AIRBAG1			
☐ 1	Instrument panel	1994-1997, LHD, AIRBAG 1	1	46 09 566
	Ch. S2016100--, S7015188--, AIRBAG1			
☐ 1	Instrument panel	LHD, AIRBAG 2, NLS-USE 4609574	1	42 19 226
	Ch. --S2016099, --S7015154, AIRBAG2			
☐ 1	Instrument panel	1994-1997, LHD, AIRBAG 2	1	46 09 574
	Ch. S2016100--, S7015155--, AIRBAG2			
☐ 1	Instrument panel	RHD, AIRBAG 1, NLS-USE 4609582	1	42 19 242
	Ch. --S2016099, --S7015144, AIRBAG1			
☐ 1	Instrument panel	1994-1997, RHD, AIRBAG 1	1	46 09 582
	Ch. S2016100--, S7015145--, AIRBAG1			
☐ 1	Instrument panel	RHD, AIRBAG 2, NLS-USE 4849014	1	44 20 683
	Ch. --S2016636, --S7015100, AIRBAG2			
☐ 1	Instrument panel	1994-1997, RHD, AIRBAG 2	1	46 09 590

Start

The Saab Network ...

saabpics.org - Welc...

Scoville scale - Wiki...

EPC

9:22 PM

Vehicle Information



VIN : YS3DP35G8

X7058811

Decode



OK

Engine : B235R

4-CYL,TURBO,4-CYL TURBO,PET

Cancel

Gearbox : M

Drive : All

Clear

Help

Market Code : All

Filter


☒ On

☐ Off

Decoded Information

Car line	D	Saab 9-3
Market	P	Model series VI, Driver and passenger airbags
Body Type	3	3-door
Gearbox	5	5-speed manual
Engine	G	B235R 4-inline, Turbo
Check digit	8	
Model Year	X	1999
Assembly Plant	7	Nystad, Finland (900 / 9-3)
Serial Number		058811

Cooling system - Coolant pump (1998 - 2000), 4-CYL, PETROL




F9150 AAC98

Parts Picklist Notes

Pos	Article	Usage	Qty	Part No.
☐ 1	Coolant pump	B204E, B204I, B204L, B204R, B234I	1	88 22 793
☐ 1	Coolant pump	B205, B235	1	88 22 710
☐ 2	•Gasket		1	91 44 767
☐ 3	•O-ring		1	91 46 598
☐ 4	•O-ring		1	91 46 606
☐ 5	•O-ring	B204E, B204I, B204L, B204R, B234I, B205L, B205R	1	91 46 614
☐ 5	•O-ring	B235R	1	91 46 606
☐ 6	•Pump connection	B204E, B204I, B204L, B204R, B234I	1	91 87 691
☐ 6	•Pump connection	B205, B235	1	91 73 741
☐ 7	•Screw		7	80 59 586
☐ 8	Tube	B204E, B204I, B204L, B204R, B234I, B205L, B205R	1	91 37 514
☐ 8	Tube	B235R	1	91 77 031
☐ 11	Tube	B204E, B204I, B204L, B204R, B234I, B205L, B205R	1	91 46 549
☐ 11	Tube	B235R	1	91 82 544
☐ 12	Tube		1	91 46 523
☐ 14	Screw		1	79 78 109
☐ 15	Screw	B204E, B204I, B204L, B204R, B234I, B205L, B205R	3	79 71 294
☐ 15	Screw	B235R	3	79 72 466

Lighting - Tail lamp (1998 - 2000)



Parts Picklist Notes


Pos	Article	Usage	Qty	Part No.
☐ 1	Tail lamp	5D, 3D, LH	1	48 31 061
☒ 1	Tail lamp	5D, 3D, RH	1	48 31 095
☐ 1	Tail lamp	CV, LH	1	48 31 129
☐ 1	Tail lamp	CV, RH	1	48 31 137
☐ 1A	Seal		2	48 31 087
☐ 2	Bulb socket	LH	1	48 31 079
☐ 2	Bulb socket	RH	1	48 31 103
☐ 3	Bulb		1	44 68 930
☐ 4	Bulb		1	43 20 594
☐ 5	Bulb		1	43 20 594
☐ 6	Nut		6	79 77 929

Model SAAB 9-3 2000

Group 3A Electrical, general

Section 0490 Filter ON

Clutch operation - Clutch pedal (1998 - 2000)




Parts Picklist Notes

Pos	Article	Usage	Qty	Part No.
☐ 6	• Lock nut		1	73 99 801
☐ 7	• Clutch cylinder		1	46 26 172
☐ 7A	• Lock ring		1	49 40 722
☐ 8	• Pin		1	49 25 541
☐ 9	• Clip		1	43 45 443
☐ 10	• Lock nut		2	79 65 767
☐ 11	• Clip		1	82 52 553
☐ 12	• Spring guide		1	40 00 568
☒ 14	• Helper spring		1	48 39 296
☐ 15	• Spring guide		1	89 57 813
☐ 16	• Pedal stop		1	48 39 312
☐ 17	• Nut		1	80 74 106
☐ 18	• Clutch pedal	LHD	1	46 49 596
☐ 18	• Clutch pedal	RHD	1	46 49 646
☐ 19	Edge protection moulding		1	48 67 016
	Ch. X2086166--			
☐ 22	Pedal bracket		1	42 12 130
☐ 23	Nut		2	43 45 419
☐ 24	Washer		1	43 45 344
☐ 25	Nut		1	79 71 922
	27	Steering wheel member Goto 6 - 160		
☐ 28	Nut		1	79 71 922
☐ 31	Clutch hose	1999-2000, LHD	1	49 25 582
☐ 31	Clutch hose	LHD, CA, US	1	49 25 582
	Ch. X2086166--			



Vehicle Content Illustration Pick List Search Administration

Gearbox control, manual - Gear lever (1998 - 2000), M



Parts Picklist Notes


Pos	Article	Usage	Qty	Part No.
☐ 1	Lever stop		1	44 91 411
☐ 2	Gear lever		1	45 80 015
☐ 3	•Ball		1	40 27 876
☐ 4	•Bushing		2	40 27 892
☐ 5	•Washer		2	41 21 588
☐ 6A	•Roll pin		2	46 85 657
☐ 7	Knob		1	49 04 405
☐ 7A	•Emblem	Goto 4 - 670	1	49 04 843
☐ 7	Knob leather		1	49 04 413
☐ 7A	•Emblem leather		1	49 04 827
☐ 8	Companion flange		1	40 27 868
☐ 9	Spring		1	44 77 204
☐ 10	Ball socket		1	44 77 824
☐ 11	Ball socket		1	40 27 850
☐ 12	Spring		1	40 27 942
☐ 13	Reverse lock		1	44 90 314
☐ 14	Bushing		2	75 59 875
☐ 15	Spacer		1	75 77 729
☐ 35	Screw		1	80 83 966
☐ 36	Frame		1	43 86 322
☐ 36	Frame leather		1	46 26 826
☐ 39	Gaiter		1	42 82 901

Model SAAB 9-3 2000

Group 4 Transmission

Section 0370 Filter ON


Front suspension (1998 - 2000)



Parts Picklist Notes

Pos	Article	Usage	Qty	Part No.
	green			
☐ 6	Spacer		2	47 79 724
☐ 7	Spring support		2	47 79 310
☐ 8	Spring disc		2	47 78 726
☐ 9	Thrust bearing		2	42 46 377
☐ 10	Support bearing	1998-1999	2	49 08 562
☐ 12	Lock nut		2	79 79 537
☐ 13	Hexagon nut		6	79 77 952
☐ 14	Washer		2	80 73 249
☐ 16	Protecting cover		2	48 38 108
☐ 16	Protecting cover	1999-2000, VIGGEN, LH	1	48 38 108
☐ 16	Protecting cover	1999-2000, VIGGEN, RH	1	51 22 577
☐ 20	Anti-roll bar	CODE=A	1	45 43 492
☐ 20	Anti-roll bar	CODE=B	1	45 43 500
☐ 20	Anti-roll bar	CODE=G	1	49 05 824
☐ 21	•Link		2	45 44 599
☐ 22	•Lock nut		2	43 47 357
☐ 23	Bushing		2	45 43 518
	For anti-roll bar 4543492.			
☐ 23	Bushing		2	45 43 526
	For anti-roll bar 4543500.			
☐ 23	Bushing		2	49 05 832
	For anti-roll bar 4905824.			


Rear axle (1998 - 2000)



Parts Picklist Notes

Pos	Article	Usage	Qty	Part No.
☐ 1	Rear axle		1	44 67 619
☐ 2	Bushing		2	44 67 791
☐ 3	Nut plate		2	43 73 734
☐ 4	Anti-roll bar	CODE=A	1	44 67 437
☐ 4	Anti-roll bar	CODE=B	1	44 82 535
☐ 5	Rubber damper		1	42 49 272
☐ 6	Hexagon screw		2	43 46 375
☐ 7	Washer		2	79 33 856
☐ 8	Hexagon nut		2	43 46 342
9	Bearing	Goto 5 - 130		
☐ 10	Screw		2	79 78 190
☐ 11	Nut		2	80 74 288
☐ 12	Anti-roll bar		1	42 47 896
☐ 13	Screw		4	79 78 232
☐ 14	Hexagon screw		2	79 85 054
☐ 15	Flange lock nut		2	79 77 820
☐ 16	Retainer Handbrake cable	LH	1	44 67 411
☐ 16	Retainer Handbrake cable	RH	1	44 67 403
17	Bracket	Goto 5 - 220		

Doors, boot lid - Door lock - Front door (1998 - 2000), 3D, CV



Parts Picklist Notes

Pos	Article	Usage	Qty	Part No.
☐ 9	Spacer	RH	1	45 50 364
☐ 10	End plate	3D	2	48 55 979
☐ 10	End plate	CV	2	48 55 979
☐ 12	Screw		4	46 85 624
☐ 13	Rod	LH	1	43 25 437
☐ 13	Rod	RH	1	43 25 445
☒ 14	Clip		4	43 46 102
☐ 15	Rod	LH	1	43 25 452
☐ 15	Rod	RH	1	43 25 460
☐ 16	• Lock button		1	40 37 735
☐ 17	Control rod	3D, LH	1	51 16 496
☐ 17	Control rod	3D, RH	1	51 16 504
☐ 17	Control rod	CV, LH	1	51 16 512
☐ 17	Control rod	CV, RH	1	51 16 520
☐ 18	Rod	LH	1	47 65 970
☐ 18	Rod	RH	1	47 65 988
☐ 20	Clip		2	44 21 046
☐ 25	Opening handle	LH	1	46 05 952
☐ 25	Opening handle	RH	1	46 05 960
☐ 25	Opening handle	LH, CHROME	1	48 21 807

EPC
File Edit View Tools Info Help

VIN DMS English ? ?

Vehicle Content Illustration Pick List Search Administration

External details - Door and side windows (1998 - 2000), 3D


F8015 AAC03

Parts Picklist Notes

Pos	Article	Usage	Qty	Part No.
☐ 1	Door window Heat-absorbing glass	1999-2000, LH	1	51 81 110
☐ 1	Door window Heat-absorbing glass	1999-2000, RH	1	51 81 128
☐ 5	Guide rail	LH	1	43 25 718
☐ 5	Guide rail	RH	1	43 25 726
☐ 6	Screw		4	79 78 091
☐ 8	Seal	LH	1	43 25 577
☐ 8	Seal	RH	1	43 25 585
☐ 9	Seal	LH	1	43 25 593
☐ 9	Seal	RH	1	43 25 601
☐ 10	Side window Heat-absorbing glass	LH	1	43 07 351
☐ 10	Side window Heat-absorbing glass	RH	1	43 07 369
☐ 11	Nut		10	73 98 423

Start | The Saab Network Chat - ... | TSN 1987-93 & 94 Saab 9... | **EPC** | 7:46 PM

External details - Decor (1998 - 2000), 3D, CV



Parts Picklist Notes


Pos	Article	Usage	Qty	Part No.
☐ 1	Decor strip	LH	1	42 40 958
☐ 1	Decor strip	RH	1	42 40 966
☐ 1A	•Bushing		2	44 69 854
☐ 2	Decor strip	LH	1	42 48 118
☐ 2	Decor strip	RH	1	42 48 100
☐ 3	•Clip		7	42 45 957
☒ 4	•Bushing		8	44 69 854
☐ 5	Decor strip	LH	1	42 48 159
☐ 5	Decor strip	RH	1	42 48 142
☐ 6	•Clip		3	42 45 957
☐ 7	•Bushing		4	44 69 854
☐ 10	Sill protection	LH	1	42 48 035
☐ 10	Sill protection	RH	1	42 48 027
☐ 11	Sill protection	LH	1	42 48 050

Model SAAB 9-3 1999

Group 8A Car body, external

Section 1210 Filter ON

External details - Decor (1998 - 2000), 3D, CV



Parts Picklist Notes

Pos	Article	Usage	Qty	Part No.
☐ 11	Sill protection	LH	1	42 48 050
☐ 11	Sill protection	RH	1	42 48 043
☐ 12	Sill cover	LH	1	49 18 439
	Exterior sports kit			
☐ 12	Sill cover	RH	1	49 18 421
	Exterior sports kit			
☐ 14	Plastic nut		14	40 87 128
☐ 15	Stone guard	LH	1	43 73 932
☐ 15	Stone guard	RH	1	43 73 924
☐ 15	Stone guard Black	AERO, LH, BC 170	1	49 12 879
	Exterior sports kit			
☐ 15	Stone guard Black	AERO, RH, BC 170	1	49 12 861
	Exterior sports kit			
☐ 15	Stone guard Cosmic blue	AERO, LH, BC 264	1	49 12 911
	Exterior sports kit			

Model SAAB 9-3 1999

Group 8A Car body, external

Section 1210 Filter ON

EPC
File Edit View Tools Info Help

VIN DMS English ?

Vehicle Content Illustration Pick List Search Administration

External details - Air shield - Spoiler (1998 - 2000)

79032 9 3
8A/ 240

Parts Picklist Notes

Pos	Article	Usage	Qty	Part No.
1	Spoiler	Goto 8A - 1600	X	
☐ 7	Air shield	LH	1	46 77 837
☒ 8	Air shield	RH	1	46 77 845
☐ 9	Hexagon screw	L=19MM	15	79 83 000
☐ 9	Screw	L=38MM	3	79 82 192
☐ 10	Nut		2	79 75 261
☐ 11	Expanding nut		4	43 33 704
☐ 12	Screw		3	79 82 325
☐ 14	Sound insulating baffle 1999-2000, DIESEL		1	49 22 779
☐ 15	Hexagon screw		2	79 83 000
☐ 16	Expanding nut		2	43 33 704
☐ 25	Spoiler		1	46 73 331
☐ 26	• Clip		2	44 01 675
☐ 27	Bushing		2	44 80 869
☐ 28	Washer		3	44 81 073
☐ 29	Nut		2	79 77 929

Start | C&C Sales & Servic... | The Saab Network ... | Yahoo! - Mozilla Fire... | EPC | 10:19 PM

EPC
File Edit View Tools Info Help

English

Vehicle Content Illustration Pick List Search Administration

External details - Air shield - Spoiler (1999 - 2000), VIGGEN


CUZU / 9-0
GB/V 1250

Parts Picklist Notes

Pos	Article	Usage	Qty	Part No.
☐ 5	Air shield	LH	1	50 84 835
☐ 6	Air shield	RH	1	50 23 957
☐ 7	• Clip nut		3	79 67 995
☐ 9	Hexagon screw		10	79 83 000
☐ 10	Nut		2	79 75 261
☐ 11	Hexagon screw		2	79 83 000
☒ 12	Cover		1	51 22 551
☐ 13	Rivet		12	51 21 041
☐ 15	Push nut		1	47 41 203
☐ 15	Rivet		7	51 21 041
☐ 20	Cover	LH	1	51 22 155
☐ 21	Cover	RH	1	51 22 148
☐ 25	Spoiler	3D, 5D	1	51 24 565
☐ 26	Spoiler	3D, 5D	1	51 24 557

Start | The Saab ... | Yahoo! M... | saabpics.o... | Web Base... | **EPC** | 7:50 PM

External details - Air shield - Spoiler (1999 - 2000), VIGGEN

C0237 9-3
08A/1250

Parts Picklist Notes

Pos	Article	Usage	Qty	Part No.
☐ 15	Push nut		1	47 41 203
☐ 15	Rivet		7	51 21 041
☐ 20	Cover	LH	1	51 22 155
☐ 21	Cover	RH	1	51 22 148
☐ 25	Spoiler	3D, 5D	1	51 24 565
☒ 26	Spoiler	3D, 5D	1	51 24 557
	Paintable design			
☐ 30	Attachment	3D, 5D, LH	1	51 24 649
☐ 30	Attachment	3D, 5D, RH	1	51 24 631
☐ 31	Screw	3D, 5D	4	79 78 380
☐ 32	Nut	3D, 5D	3	79 77 929
☐ 33	Washer	3D, 5D	3	79 75 469
☐ 34	Sealing washer	3D, 5D	3	44 01 733
☐ 36	Screw	3D, 5D	2	80 56 012
☐ 37	Screw	3D, 5D	6	79 86 235
☐ 40	Spoiler	CV	1	47 86 521
	Paintable design			
☐ 41	Nut	CV	5	79 77 911
☐ 42	Seal	CV	4	49 59 607
☐ 43	Washer	CV	5	92 30 293
☐ 44	Seal	CV	1	49 10 154



File Edit View Tools Info Help

VIN DMS English ?

Vehicle Content Illustration Pick List Search Administration

Bumpers - Bumper, front - Standard (1998 - 2000)

00408 3 3
08A/1500

Parts Picklist Notes

Pos	Article	Usage	Qty	Part No.
☐ 1	Bumper Paintable design		1	49 56 181
☐ 2	• Cover Paintable design	1999-2000	1	49 57 205
☐ 3	• Bumper rail		1	42 48 712
☐ 4	• Foam part		1	46 76 367
☐ 6	• Retainer	LH	1	46 76 730
☐ 6	• Retainer	RH	1	46 76 722
☐ 17	Bracket		2	49 15 252
☐ 18	Grille fog-lights	LH	1	45 64 852
☐ 18	Grille fog-lights	RH	1	45 64 860
☐ 19	Grille	LH	1	45 64 878
☐ 19	Grille	RH	1	45 64 886
☐ 20	Screw		2	73 99 884
☐ 21	Washer		2	80 73 108
☐ 22			2	73 73 691

1:05 PM

File Edit View Tools Info Help

VIN DMS English

Vehicle Content Illustration Pick List Search Administration

Bumpers - Bumper, front (1999 - 2000), VIGGEN

Diagram showing the front bumper assembly components and their installation points on the vehicle.

Parts Picklist Notes


Pos	Article	Usage	Qty	Part No.
	Bumpers	STANDARD Goto 8A - 1600		
	Bumpers	AERO, Exterior Sports Kit, Aero Goto 8A - 1605		
☐ 1	Cover Paintable design		1	51 20 282
☐ 2	Grille		1	50 20 458
☐ 3	Clamp		8	52 83 411
☐ 4	Cover		1	51 24 441
☐ 5	Bumper rail		1	42 48 712
☐ 6	Foam part		1	46 76 367
☐ 7	Retainer	LH	1	51 22 668
☐ 7	Retainer	RH	1	51 22 650
☐ 9	Clip		2	44 00 644
☐ 10	Seal		2	51 22 692
☐ 16	Adapter		2	51 23 435
☐ 17	Bracket		2	49 15 252

C0238 9-3
08A/1610

Start
The Saab ...
Yahoo! M...
saabpics.o...
Web Base...
EPC

7:39 PM


Dashboard - Centre console (1998 - 2000)



Parts Picklist Notes

Pos	Article	Usage	Qty	Part No.
☐ 1	Front section	LHD	1	50 15 953
☐ 1	Front section	RHD	1	50 15 961
☐ 1A	• Cigarette lighter socket		1	50 14 246
☐ 1B	• Light guide		1	50 14 253
☐ 2	• Rubber mat	LHD	1	44 20 626
☐ 2	• Rubber mat	RHD	1	44 20 634
☐ 3	Side part	LHD, LH	1	47 09 960
☐ 3	Side part Light beige	1998-1999, LHD, RH	1	47 09 986
☐ 3	Side part Light beige	1998-1999, RHD, LH	1	47 40 023
☐ 3	Side part Light beige Ch. W2057988-- Ch. W7053726--	RHD, RH	1	49 04 074
☐ 3	Side part Grey	LHD, LH	1	47 09 952
☐ 3	Side part Grey	1998-1999, LHD, RH	1	47 09 978
☐ 3	Side part Grey	1998-1999, RHD, LH	1	47 40 007
☐ 3	Side part Grey Ch. W2057988-- Ch. W7053726--	RHD, RH	1	49 04 066
☐ 3	Side part Black	LHD, LH	1	44 71 553


Dashboard - Centre console (1998 - 2000)



Parts Picklist Notes

Pos	Article	Usage	Qty	Part No.
☐ 3A	• Nut	RHD	1	96 92 849
☐ 3B	• Cover Grey		1	48 49 923
☐ 3B	• Cover Light beige		1	48 49 964
☐ 3B	• Cover Black		1	49 30 541
☐ 4	Screw		2	97 71 320
☐ 5	Centre console		1	47 41 930
☐ 6	• Brush		2	42 18 673
☐ 7	• Clip nut		1	79 68 001
☐ 8	• Retainer		1	50 11 978
☐ 8A	• Clamp		1	93 83 043
☐ 9	Cup holder	CA, PA, US	1	48 84 318
☐ 10	Screw	NLS-USE 7970536	1	79 82 218
☐ 11	Nut		2	79 74 298
☐ 12	Cover	3D, 5D	1	47 07 535
☒ 12	Cover	CV	1	48 16 203
☐ 17	Box		1	49 39 872
☐ 18	Cover		1	50 15 607
☐ 18	Cover Ch. -X2087749		1	51 71 889
☐ 19	Ashtray		1	47 07 295
☐ 20	Lighter unit		1	50 14 279
☐ 21	Cover		1	47 41 633

Dashboard - Centre console (1998 - 2000)




C0165 9-3
08B/0150

Parts Picklist Notes

Pos	Article	Usage	Qty	Part No.
☐ 19	Ashtray		1	47 07 295
☐ 20	Lighter unit		1	50 14 279
☐ 21	Cover		1	47 41 633
☐ 22	Cover		1	47 41 682
☐ 23	Rubber mat		1	44 21 384
☐ 23	Rubber mat	For cars with armrest.	1	50 11 838
☐ 24	Ashtray		1	49 04 660
☐ 24	Ashtray	Ch. W2061857-- Ch. W7054563--	1	48 84 300
☐ 24	Ashtray	LHD, CA, US	1	48 84 300
☐ 24	Ashtray	Ch. -X2005874 Ch. -X7002213	1	48 84 300
☐ 24	Ashtray	LHD, CA, US	1	49 04 660
☐ 24	Ashtray	Ch. X2005875-- Ch. X7002214--	1	49 04 660
☐ 25	Cover		1	48 84 292
☐ 26	Screw		X	79 77 002
☐ 27	Clip nut		2	79 67 995
☐ 28	Expanding rivet		2	44 70 639
☐ 29	Screw		1	79 78 380
☐ 30	Bracket		1	44 88 193
☐ 31	•Clip nut		1	79 67 995
☐ 33	Blind knob	Goto 3A - 760	1	
☐ 34	Blind knob	Goto 3A - 760	1	


Upholstery - Door trim - Front door (1998 - 2000)



F9985 9-3
083/0280

Pos	Article	Usage	Qty	Part No.
☐ 2	• Loudspeaker grille Grey Ch. X2050001-- Ch. X7024838--		1	47 05 273
☐ 2	• Loudspeaker grille Black		1	44 72 569
☐ 3	• Lock washer		3	44 73 484
☐ 4	• Clamp		X	47 05 331
☐ 5	• Clamp		X	44 98 341
☐ 6	• Spacer		1	42 17 188
☐ 7	• Washer	1998-1999	1	96 71 389
☐ 8	• Washer		X	97 97 200
☐ 9	• Door pull Light beige	LH	1	50 02 415
☐ 9	• Door pull Light beige	RH	1	50 02 423
☐ 9	• Door pull Grey	LH	1	50 02 399
☐ 9	• Door pull Grey	RH	1	50 02 407
☐ 9	• Door pull Black	LH	1	44 72 593
☐ 9	• Door pull Black	RH	1	44 72 627
☐ 10	• Cover Light beige	LH	1	50 02 290
☐ 10	• Cover Light beige	RH	1	50 02 308
☐ 10	• Cover	LH	1	50 02 374

Upholstery - Luggage compartment (1998 - 2000)



Parts Picklist Notes

Pos	Article	Usage	Qty	Part No.
☐ 4	• Clip		3	42 66 540
☐ 5	Upholstery	3D, 5D	1	47 07 527
☐ 5	Upholstery	CV	1	43 70 771
☐ 6	• Clip nut		2	79 68 001
☐ 7	• Clamp		2	41 40 315
☐ 9	Rivet	3D, 5D	5	46 81 565
☐ 9	Special screw	CV	X	94 64 926
☐ 10	Quick nut	CV	X	84 52 898
☒ 11	Screw		2	97 71 320
☐ 12	Nut		2	79 75 261
☐ 13	Sill protection	3D, 5D	1	48 21 500
☐ 13	Sill protection	CV	1	46 40 678
☐ 14	• Clamp	3D, 5D	4	43 88 757
☐ 17	Luggage compartment 3D, 5D, LH trim/lining		1	47 47 440
☐ 17	Luggage compartment 3D, 5D, RH trim/lining		1	47 47 457
☐ 17	Luggage compartment CV, LH trim/lining		1	47 47 465
☐ 17	Luggage compartment CV, RH trim/lining		1	50 25 242
18	• Lamp	LH Goto 3A - 550	1	
☐ 19	• Clamp		1	41 40 315
☐ 21	Push nut		X	47 41 203

File Edit View Tools Info Help

VIN DMS English

Vehicle Content Illustration Pick List Search Administration

Accessories body - Towing hitch (1998 - 2000)

Parts Picklist Notes


Pos	Article	Usage	Qty	Part No.
☐ 12	• Cover		1	400 109 526
☐ 13	• Control unit lockable		1	400 126 215
	•• Cover Upper section		1	
	Not as separate spare part.			
	•• Lock cylinder		1	
	Not as separate spare part.			
	•• Cover Lower section		1	
	Not as separate spare part.			
	•• Screw		4	
	Not as separate spare part.			
☐ 14	•• Lock cap		1	400 126 207
☐ 15	Towbar	LHD, US	1	400 110 664
	Not for the Viggen.			
☐ 16	• Towing member	LHD, US	1	400 104 113
☒ 17	• Cable harness kit	LHD, US	1	400 103 438
☐ 18	• Socket	LHD, US	1	400 104 055

The Saab Network Chat - ...

Saabnet.com: 900 BB Pos...

7:00 PM


Gearbox control, manual - Gear lever (1998 - 2000), M



Parts Picklist Notes

Pos	Article	Usage	Qty	Part No.
☐ 1	Gear lever		1	49 26 507
☐ 1A	• O-ring		1	79 77 424
☐ 2	• Lever stop		1	49 26 499
☐ 3	• Ball		1	40 27 876
☐ 4	• Bushing		2	40 27 892
☐ 5	• Washer		2	41 21 588
☐ 6	• Roll pin		2	46 85 657
☐ 7	Knob		1	45 78 357
☐ 7	Knob leather		1	45 78 928
☐ 8	Companion flange		1	45 79 793
☐ 9	Spring		1	45 79 785
☐ 10	Ball socket		1	44 77 824
☐ 11	Ball socket		1	40 27 850
☐ 12	Spring		1	40 27 942
☐ 13	Reverse lock		1	44 90 314
☐ 14	Bushing		2	75 59 875
☐ 15	Spacer		1	75 77 729
☐ 16	Screw		1	80 83 966
☐ 17	Frame	LHD	1	45 78 407
☐ 17	Frame	RHD	1	45 78 399
☐ 18	Bracket		1	46 25 091
☐ 19	Rivet		1	79 72 490
☐ 20	Gaiter		1	47 77 322

Gearbox control, automatic - Gear selector lever (1998 - 2000), A



Parts Picklist Notes


Pos	Article	Usage	Qty	Part No.
☐ 1	Gear changing unit	LHD	1	47 77 702
☐ 1	Gear changing unit	LHD, CA, US	1	51 62 227
☐ 1	Gear changing unit	RHD	1	47 77 686
☐ 1	Gear changing unit	RHD, AU, PA	1	51 62 201
☐ 2	•Gear lever		1	47 77 629
☐ 3	••Gear lever	NLS	1	45 79 405
☐ 4	••Striker plate	NLS	1	47 77 439
☐ 5	••Leading tube	NLS	1	47 77 470
☐ 6	••Washer		1	51 62 722
☐ 7	••Bushing		1	51 62 714
☐ 8	••Ball	NLS	1	47 77 520

Model SAAB 9-5 2000

Group 4 Transmission

Section 0610 Filter ON


Footbrake system - Brake lines ABS (1998 - 2000)



Parts Picklist Notes

Pos	Article	Usage	Qty	Part No.
☐ 17	Bracket	RH	1	49 09 107
☐ 18	Wheel speed sensor		2	49 09 966
☐ 19	Screw		2	79 78 133
☐ 20	Bracket	LH	1	48 35 781
☐ 20	Bracket	RH	1	48 35 799
☐ 21	Screw		2	79 78 117
☐ 22	Bracket	LH	1	45 68 119
☐ 22	Bracket	RH	1	45 68 127
☐ 23	Clamp		3	48 35 005
☐ 24	Tube clamp		X	42 43 077
☐ 25	Tube clamp		1	48 38 512
☐ 26	Clamp		2	48 36 805
☐ 27	Tube clamp		2	91 06 139
28	Tube clamp	Goto 2 - 580		
29	Hydraulic unit	Goto 5 - 160		
☐ 30	Tube clamp		2	89 65 097
☐ 31	Clamping spring Ch. X3025752--		2	50 58 193
☐ 32	Bracket Ch. X3025752--		2	50 56 593
☒ 33	Flange lock nut Ch. X3025752--		4	43 45 153
☐ 34	Brake hose Ch. X3025752--		2	49 08 695
35	Brake housing	Goto 5 - 130		

External details - Door mirrors (1998 - 2000)



Parts Picklist Notes

Pos	Article	Usage	Qty	Part No.
☐ 9	• Gasket Mirror base	LH	1	51 16 249
☐ 9	• Gasket Mirror base	RH	1	51 13 857
☐ 10	Screw		8	79 78 422
☐ 11	Cover Paintable design Ch. X3070507--	LH	1	51 82 837
☐ 11	Cover Paintable design Ch. X3070507--	RH	1	51 82 845
☐ 12	Cover Paintable design Ch. W3070001--	LH	1	43 69 187
☐ 12	Cover Paintable design Ch. W3070001--	RH	1	43 69 195
13	• Label	Goto 8D - 160	1	
☐ 15	Screw		2	46 43 771
☐ 18	Mirror glass	LHD, CN, EU, LA, PA, LH, WIDE ANGLE	1	46 43 706
☐ 18	Mirror glass	LHD, ME, LH, WIDE ANGLE	1	48 81 785
☐ 18	Mirror glass	LHD, CA, US, LH, FLAT	1	46 43 748
☐ 18	Mirror glass	RHD, AU, EU, GB, PA, LH, WIDE ANGLE	1	46 43 706