

Utfärdare  
Issued by **AFTPT Bertil Gustafsson**

Datum  
Date **78-10**

Distr.

**HUB CAPS FOR STEEL WHEELS, 1979 MODEL**


## Attachment

**Attachment**  
The hub caps are attached by clips which are supplied by the factory in a plastic bag in the glove compartment.

## Removal

### Removal

Hub caps are best removed by pressing inwards at the edge of the cap with your hand so tilting the cap and lifting the opposite edge away from the wheel, allowing access.

[illegible]

Personbilsdivisionen  
Saab Car Division

Postadress  
611 81 NYKÖPING

Postal Address  
S-611 8  
Sweden

